


# K-BUS KNX-DALI-2 Gateway, 1/2-Fold\_V1.7

**BTDG-01/64.2**

**BTDG-02/64.2**



# KNX/EIB Home and Building Control System

# Attentions

1. Please keep devices away from strong magnetic field, high temperature, wet environment;



2. Do not fall the device to the ground or make them get hard impact;



3. Do not use wet cloth or volatile reagent to wipe the device;



4. Do not disassemble the devices.

# Contents

Chapter 1 Summary .....	1
1.1. DALI System Introduction .....	1
1.2. Product and Function Description .....	2
Chapter 2 Technical Data .....	3
Chapter 3 Dimension and Connection Diagram .....	5
3.1. Dimension Diagram .....	5
3.2. Connection Diagram .....	6
Chapter 4 Project Design and Application .....	8
4.1. Schematic .....	8
4.2. Overview of Functions .....	8
4.2.1. Gateway Initialization .....	8
4.2.2. Control of a Single DALI Device .....	8
4.2.3. Self-contained battery lamp .....	10
4.2.4. Group Control .....	11
4.2.5. Scene Control .....	13
4.2.6. Broadcast Control .....	13
4.2.7. Operation Mode .....	14
4.2.8. Operation hour calculation .....	16
4.2.9. ECG Failure or Lamp Failure Identification .....	17
4.2.10. Device Failures Number and Failure Rate Analysis .....	17
4.2.11. Colour Temperature Adjustment .....	18
4.2.12. RGB(W) adjustment .....	19
4.2.13. XY adjustment .....	20
4.2.14. Motion and brightness sensor .....	20
4.3. Operation Steps .....	21
Chapter 5 Parameter Setting Description in the ETS .....	23
5.1. KNX Secure .....	23
5.2. Parameter window“General” .....	27
5.3. Parameter window“DALI Output A/B” .....	30
5.4. Parameter window“ECG/Group Template setting” .....	41
5.4.1. Parameter window“Template X(X=1~8)” .....	41
5.5. Parameter window“Emergency Template setting” .....	48
5.5.1. Parameter window“Template X(X=1~8)” .....	48
5.6. Parameter window“Group setting” .....	50

5.6.1. Parameter window "Group X" (X=1~16) .....	50
5.6.1.1. Operation mode "Normal mode" .....	52
5.6.1.2. Operation mode "Normal/Night mode" .....	53
5.6.1.3. Operation mode "Staircase mode" .....	55
5.6.1.4. Operation mode "Permanent mode" .....	56
5.6.2. Parameter window "Colour control" .....	57
5.6.2.1. Colour control type "Colour Temperature" .....	58
5.6.2.2. Colour control type "RGB Colour" .....	60
5.6.2.3. Colour control type "RGBW Colour" .....	62
5.6.2.4. Colour control type "XY Colour" .....	64
5.6.3. Parameter window "Scene" .....	66
5.7. Parameter window " ECG setting" .....	69
5.7.1. Parameter window "ECG X" (X=1~64) .....	69
5.7.1.1. Parameter setting "LED Module/ECG with Colour control/Relays module" .....	71
5.7.1.2. Parameter setting "Self-Contained Battery Lamp (non-switchable)" .....	77
5.7.2. Parameter window "Colour control" .....	78
5.7.2.1. Colour control type "Colour Temperature" .....	79
5.7.2.2. Colour control type "RGB Colour" .....	83
5.7.2.3. Colour control type "RGBW Colour" .....	86
5.7.2.4. Colour control type "XY Colour" .....	89
5.8. Parameter window "Motion sensor setting" .....	91
5.8.1. Parameter window "Motion sensor X" (X=1~8) .....	92
5.8.2. Parameter window "Brightness sensor" .....	96
Chapter 6 Description of Communication Object .....	98
6.1. General Communication Object .....	98
6.2. Channel General Communication Object .....	99
6.3. Channel Communication Object of a Single Group .....	107
6.4. Channel Communication Object of a Single DALI Device .....	113
6.5. Channel Communication Object of a Single DALI Sensor .....	120

## Chapter 1 Summary

KNX-DALI-2 Gateway, 1/2-Fold is designed for KNX intelligent building control system and used to connect KNX bus and DALI bus. As the interface between KNX installation system and DALI network, messages from the KNX bus can be converted into information that can be identified by the DALI device via this gateway. The information contains the DALI device address and command, and send to the DALI network to control the DALI device, thus to realize the functions of switching, dimming, brightness value, colour temperature, colour control, etc. of various lamps etc. of various lamps with DALI ballasts, while the DALI gateway can request the status of the DALI device, failure detection, and convert the status and failure information into KNX telegrams, and send to the KNX bus.

KNX-DALI-2 Gateway, 1/2-Fold has two product types with 1-Fold and 2-Fold output. Each channel can connect up to 64 DALI devices. Each DALI device can be controlled by a direct switching, dimming, brightness value, colour temperature, colour control by using a KNX communication object. The assignment of DALI device addresses can be done manually or automatically. At the same time, we provide DCA tool for users to easily modify the address, test, and assign groups and scenes to the DALI device, etc.

**Note: DCA is a App plug-in in ETS embedded in the application of the product.**

This manual provides detailed technical information about the KNX-DALI-2 Gateway, 1/2-Fold including installation and programming details, and explains how to use it in the practical examples.

### 1.1. DALI System Introduction

In the same DALI network, there are up to 64 slave units, each with a separate address (Short address). It is also possible to assign a slave unit to a group (up to 16 groups can exist at the same time). The host can also send information to all slave units. The main features of the DALI protocol: asynchronous serial communication, 1200 baud rate, two-wire differential signal, a DALI bus can be connected to 64 slaves, each slave can be individually addressed, but can not bi-direction communication at the same time.

## **1.2. Product and Function Description**

KNX-DALI-2 Gateway, 1/2-Fold is a modular mounting device. For easy installation into the distribution box, it can be mounted on a 35 mm DIN-rail according to EN 60 715. The device is screwed to the electrical connection and the bus connection is directly through the KNX. Connect the terminal block and input the power supply voltage of 100~240V AC. For the assignment of physical addresses and parameter settings, the engineering tool software ETS (version ETS5.7.7 or higher) with the .knxprod file can be used.

The main functions of the KNX-DALI-2 Gateway, 1/2-Fold are summarized as follows:

- ♦ One/Two output channels, 64 DALI devices per channel, each DALI device can be individually switching, dimming, set brightness value, colour control, etc.
- ♦ Multiple device types are available, such as DT6-LED dimming control device, DT8-colour control device, colour control type including RGB Colour, RGBW Colour, XY Colour, Colour Temperature, as well as DT7-relays module and DT1-Self-contained battery lamp
- ♦ Group control: up to 16 different groups for each channel. Assign DALI devices to groups via the DCA. And switching, dimming control, colour control for each group
- ♦ 16 different DALI scenes for each channel. And the brightness value of scenes are configured by the DCA
- ♦ 8 DALI Sensor for each channel, enabling control with motion and brightness sensors
- ♦ Group scenes or global scenes in DALI channels can be recalled via KNX scenes
- ♦ Broadcast control: switching, brightness, colour temperature, colour control for all DALI devices of a channel
- ♦ Operation mode: support normal mode, normal/night mode, staircase mode, permanent mode, burn in mode
- ♦ 8 behaviour templates for group and ECG action setting and a ECG configuration which can be modified by the DCA
- ♦ Send or response various status, such as switch, brightness, operation hours etc.
- ♦ Fault detection of lamps and ballasts for DALI devices
- ♦ Monitoring DALI bus voltage, DALI bus current and DALI bus short circuit status
- ♦ Support the KNX Data Secure

**Note: The DT1, DT7 devices and DALI sensors are suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

## Chapter 2 Technical Data

<b>Power Supply</b>	Bus voltage	21-30V DC, via the KNX bus
	Bus current	9.5mA/30V DC 11.0mA/24V DC
	Bus consumption	<285mW
	DALI Output	
	Voltage	100~240V AC, 50/60Hz
	Current	<55mA, 220V AC
	Consumption	<12W, 220V AC
<b>DALI Output</b>	1/2 Channel	Max.64 DALI devices per channel
		Max.8 DALI sensors per channel
	Current	Guaranteed supply:160mA Maximum supply: 250mA Note: The number of DALI operating devices and DALI sensors must be designed, so that the total current consumption of 160mA per DALI system is not exceeded.
	Load voltage	15~19V DC
<b>Connections</b>	KNX	Bus connection terminal (Red/Black)
	Inputs and output	Using screw terminals
<b>Operation and display</b>	Programming button and Red	Used to assign physical addresses
	LED	
	Green LED flashing	Indicates that the device application layer is working normally.
	LED (Tele.)	Fast flashing indicates that the DALI bus is being initialized; Flashing during communication, indicating that there is received message data on the DALI bus; Permanent lamp indicates that DALI bus initialization is complete

LED (Status)		The LED indicates that the entire channel switch is on, and the off indicates that the entire channel is off. It is only applicable to the channel A and B control indications and the channel's broadcast switch control indication (single channel device only A)LED flashes, indicating that the DALI gateway is initializing
Test/Set button		Short press <5s: for on/off all DALI devices to test unconnected DALI devices;  Long press >5s: reinitialize DALI bus
<b>Temperature</b>	Operation	-5°C...+45°C
	Storage	-25°C...+55°C
	Transport	-25°C...+70°C
<b>Ambient</b>	Relative humidity	<93%, Except for condensation
<b>Mounting</b>	Mounted on a standard 35mm DIN rail, DIN EN 60 715	
<b>Size</b>	72mm ×90mm ×64mm	
<b>Weight</b>	0.25KG	

Application	Maximum number of communication objects	Maximum group address	Maximum number of associations	Secure group addresses
KNX-DALI-2 Gateway,1-Fold/1.0 KNX-DALI-2 Gateway,1-Fold/2.0	1902	2500	2500	1000
KNX-DALI-2 Gateway,2-Fold/1.0 KNX-DALI-2 Gateway,2-Fold/2.0	3803	4500	4500	2000



## Chapter 3 Dimension and Connection Diagram

Taking dimensional and connection diagram of the KNX-DALI-2 Gateway, 2-Fold as an example, and the 1-Fold only retains channel A.

### 3.1. Dimension Diagram




Fig.3.1 Dimension Diagram

### 3.2. Connection Diagram




Fig.3.2 Dimension Diagram

① DALI output negative pole

② DALI output positive pole

③ Red LED indicates programming the physical address; Green LED flashing indicates the application layer works normally

④ Programming button

⑤ LED (Tele.):

Fast flashing indicates initializing DALI bus;

Flashing during communication, indicating that there is received telegram data on the DALI bus;

Permanent on, indicating that DALI bus initialization complete.

⑥ LED (Status)

LED on indicates that the entire channel switch is on, and the off indicator indicates that the entire channel is off. It is only applicable for the control indication of channel buttons A and B, and the switch control indication of channel broadcast.

LED flashing, indicate that the DALI gateway is initializing the configuration.

⑦ Test/Set button

Short press <5s: for on/off all DALI devices to test unconnected DALI devices

Long press >5s: reinitialize all devices on DALI bus or initialize the DALI devices without a DALI address or no action, according to the parameter "Test/Set button function via long press(>5s)" setting in [Section 5.3](#).


⑧ 230V AC auxiliary power input

⑨ KNX bus connection terminal

**Reset the device to the factory configuration: press the programming button and hold for 4 seconds then release, repeat the operation for 4 times, and the interval between each operation is less than 3 seconds**

## Chapter 4 Project Design and Application

### 4.1. Schematic



### 4.2. Overview of Functions

#### 4.2.1. Gateway Initialization

During the operation of the KNX-DALI-2 gateway, 1/2-Fold, the gateway needs to maintain consistency with the status of devices on the DALI bus. After a power-on restart or database download restart, it will automatically synchronize the status of devices on the DALI bus. This process requires some time, which is related to the number of devices connecting to the DALI bus, and generally takes at least 30 seconds.

#### 4.2.2. Control of a Single DALI Device

In the KNX-DALI-2 Gateway, 1/2-Fold application, each DALI device for each output channel can be individually switching, dimming, brightness value, colour temperature, colour control by an object, and the switching, dimming, brightness status, colour temperature, colour control status can be requested. Suitable for DT6-LED dimming control device, DT8-colour control device and DT7-relays module. Such as:

Output X ECG y – Switch (switch control for device y)

Output X ECG y – Relative Dimming (relative dimming control for device y)

Output X ECG y – Brightness value (brightness value control for device y)

Output X ECG y – Relative (percentage) colour temperature

(Relative (percentage) colour temperature e control for device y)

Output X ECG y – Absolute colour temperature (Absolute colour temperature control for device y)

Output X ECG y – RGB colour /HSV Hue(H)/HSV Saturation(S) value

(RGB colour /HSV Hue(H)/HSV Saturation(S) control for device y)

Output X ECG y – RGBW colour/White colour value (RGBW colour/White colour control for device y)

Output X ECG y – Colour XY/Colour X/Colour Y value (Colour XY/Colour X/Colour Y control for device y)

Output X ECG y – Relative HSV Hue(H)/HSV Saturation(S) value

(Relative HSV Hue(H)/HSV Saturation(S) control for device y)

Output X ECG y – Switch Status (request or respond to the switch status of device y)

Output X ECG y – Brightness Status (request or respond to the brightness status of device y)

Output X ECG y – Relative (percentage) colour temperature status

(request or respond to the Relative (percentage) colour temperature status y)

Output X ECG y – Absolute colour temperature status

(request or respond to the Absolute colour temperature status of device y)

Output X ECG y – RGB colour /HSV Hue(H)/HSV Saturation(S) value status

(request or respond to the RGB colour /HSV Hue(H)/HSV Saturation(S) value status of device y)

Output X ECG y – RGBW colour/White colour value status

(request or respond to the RGBW colour/White colour value status of device y)

Output X ECG y – Colour XY/Colour X/Colour Y value status

(request or respond to the Colour XY/Colour X/Colour Y value status of device y)

Output X ECG y – Relative HSV Hue(H)/HSV Saturation(S) value status

(request or respond to the Relative HSV Hue(H)/HSV Saturation(S) value status of device y)

In addition, for these 3 device types, the panic mode of the entire output channel can be activated via the object:

Output X – Panic mode (activate panic mode for all connected devices on output X)

It can also be configured as an emergency light controlled by the central battery, and the test mode of all emergency lights in the channel is activated via the object:

Output X – Test mode (activate test mode for all connected devices on output X)

(X=output channel A, B; y=DALI device 1..64)

**Note: The panic mode and test mode are only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### **4.2.3. Self-contained battery lamp**

In the application of KNX-DALI-2 Gateway, each DALI device for each output channel supports DT1-Self-Contained Battery Lamp (with its own independent battery, non-switchable). This device type without control and status communication objects for switching, brightness, colour temperature, colour, etc. It can only execute and record the mandatory testing of the device through the following communication objects:

Output X ECG y – Converter, test start (activate converter's duration test and function test for device y)

Output X ECG y – Converter, test result (request or respond to the converter's test result of device y)

Output X ECG y – Converter, status (request or respond to the converter's status of device y)

Output X ECG y – Converter battery, status (request or respond to the converter's battery status of device y)

When there is a power supply failure, the self-contained battery lamp will always switch to emergency mode. At this time, the lamp is powered by the internal battery. However, during commissioning and installation, it may be necessary to cut off the power to prevent continuous emergency lighting and battery discharge. To prevent the lamp from switching to emergency mode, the inhibit mode of all self-contained battery lamps in the output channel can be activated via the following communication object:

Output X – Converter inhibit mode (activate inhibit mode for all connected devices on output X)

(X=output channel A, B; y=DALI device 1..64)

**Note: Self-contained battery lamp is suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### **4.2.4. Group Control**

The KNX-DALI-2 Gateway, 1/2-Fold is available in 16 groups, and multiple DALI devices for each output channel can be switching, dimming, brightness value, colour temperature, colour controlled by an object. First, activate the group function in the ETS parameter configuration, configure its parameters, and then use the DCA tool to group the DALI devices that need to be controlled together, an ECG can belong to different groups at the same time. The following communication objects can directly switching, dimming, brightness status, colour temperature, colour control:

Output X Group y – Switch (switch control for device y)

Output X Group y – Relative Dimming (relative dimming of all devices in group y)

Output X Group y – Brightness value (brightness value control for device y)

Output X Group y – Absolute colour temperature

(Absolute colour temperature control for device y)

Output X Group y – Relative (percentage) colour temperature

(Relative (percentage) colour temperature control for device y)

Output X ECG y – RGB colour /HSV Hue(H)/HSV Saturation(S) value

(RGB colour /HSV Hue(H)/HSV Saturation(S) control for device y)

Output X ECG y – RGBW colour/White colour value

(RGBW colour/White colour control for device y)

Output X ECG y – Colour XY/Colour X/Colour Y value

(Colour XY/Colour X/Colour Y control for device y)

Output X ECG y – Relative HSV Hue(H)/HSV Saturation(S) value

(Relative HSV Hue(H)/HSV Saturation(S) control for device y)

Output X Group y – Switch Status (request or respond to the switch status of the y group device)

Output X Group y – Brightness Status (request or respond to the brightness status of the y group device)

Output X Group y – Absolute colour temperature

(request or respond to the Absolute colour temperature of the y group device)

Output X Group y – Relative (percentage) colour temperature status

(request or respond to the Relative (percentage) colour temperature status of the y group device)

Output X ECG y – RGB colour /HSV Hue(H)/HSV Saturation(S) value status

(request or respond to the RGB colour /HSV Hue(H)/HSV Saturation(S) value status of device y)

Output X ECG y – RGBW colour/White colour value status

(request or respond to the RGBW colour/White colour value status of device y)

Output X ECG y – Colour XY/Colour X/Colour Y value status

(request or respond to the Colour XY/Colour X/Colour Y value status of device y)

Output X ECG y – Relative HSV Hue(H)/HSV Saturation(S) value status

(request or respond to the Relative HSV Hue(H)/HSV Saturation(S) value status of device y)

(X=output channel A, B; y=group 1..16)

**Note: The group is configured via DCA tool, in order to make the ECG of the group control work normally, it is necessary to activate the ECGs of the group via ETS, otherwise these ECGs configured in the group are invalid.**



#### **4.2.5. Scene Control**

The scene control of the KNX-DALI-2 gateway, 1/2-Fold is divided into DALI scene、group scene and global scene. DALI scenes support recalling the internal scene settings of DALI drivers through DALI scene objects; Group scenes are used to control the target state of groups when receiving KNX scene controls; Global scenes can control custom ECG or group states through KNX scene numbers.

**DALI scene:** KNX-DALI-2 Gateway, 1/2-Fold provides an independent DALI scene control object for each output channel, allowing direct recall of the 16 standard scene controls in the corresponding DALI system through setting the object values. This functionality requires configuring the enabling of standard DALI scenes for different drivers and their corresponding states (including brightness, colour temperature, and colour) when executing scenes using the DCA tool. When a KNX device sends a DALI scene number to the DALI gateway, all ECGs configured with that scene will execute the operation to adjust the lamps to the preset state.

**Group scene:** KNX-DALI-2 Gateway, 1/2-Fold also provides 16 DALI group scene controls for each group, and the brightness, colour temperature, colour value of each group scene can be configured in the ETS. When the KNX device sends a scene number to recall a scene of a group in the DALI gateway, the gateway will send the group control command corresponding to the scene to the DALI bus.

**Global scene:** A global scene is configured via the DCA tool, in which the user can recall an ECG or group as an execution target and set the scene target state for them respectively. When the gateway receives a KNX scene control message sent on the bus, it recall the corresponding execution operation.

#### **4.2.6. Broadcast Control**

In the broadcast control mode, all DALI devices on the channel can simultaneously switching, dimming, brightness value, colour temperature, colour control. In the case of uneven brightness, the change of brightness is not synchronized, and some devices may reach the target brightness value first, some may reach the target brightness value later. When the database is not configured, clicking the test A/B button on the gateway can also switch all devices on the DALI bus in the channel.

#### **4.2.7. Operation Mode**

Following operation modes are suitable for DT6-LED dimming control device, DT8-colour control device and DT7-relays module. The panic mode and test mode are only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.

**Normal mode:** Each DALI device and each DALI group in this mode can be used for switching, dimming, brightness value, colour temperature, colour control, as well as switching status and brightness status feedback.

**Permanent mode:** The DALI device or DALI group in this mode is output with a fixed brightness value. After the gateway is reset or programmed, the DALI device or group will automatically set the preset brightness value.

**Note:** If the DALI device fails (eg. the ECG is not powered on when the gateway starts up) and the device cannot output with the preset brightness value, the device brightness value will be automatically corrected within 60 seconds. In the permanent mode, you can still control the colour or colour temperature functions of the ECG.

**Staircase mode:** In this mode, the brightness values of the DALI device and the DALI group can be set by the switching, relative dimming and brightness values. The lamp brightness output is automatically turned off after a certain period of time delaying, or can be directly turned off by the object control. If the telegram to turn on the lamp is received again within the delay time before the lamp is turned off, the delay time is re-timed.

**Normal/Night mode:** The night mode control is similar to the staircase mode or the permanent mode. The main difference is that the night mode needs to be activated by activating the night mode object. If the night mode is not activated, the DALI device or the DALI group will work in the normal mode. In night mode, the DALI device or DALI group lamps are automatically turned off after a certain period of time delaying, or output at a fixed brightness value.

**Panic mode:** The panic mode can be activated centrally via a channel object. All ECGs with panic mode enabled will switch to the setting brightness upon receiving a command. In this mode, they can no longer be controlled individually, and both group assignments and scenes are canceled. When the panic mode is stopped, these devices revert to their previous brightness or the setting on/off values and can be individually controlled again or reassigned to groups.

**Test mode (controlled by central battery ):** Through function definition, DALI-2 gateway supports the configuration of emergency lights controlled by a central battery. Any ECGs (except for self-contained battery lamps) can be configured as an emergency light, even if the ECG has been assigned to a group. Test mode can be activated centrally via a channel object. All ECGs with test mode enabled will switch to the setting brightness upon receiving a command and test for a duration time. In this mode, they can no longer be controlled individually, and both group assignments and scenes are canceled. After the test mode is finished normally, these devices revert to their previous brightness or the setting on/off values and can be individually controlled again or reassigned to groups.

**Note:**

**1.Priority of these operating modes from high to low: Test mode (controlled by central battery)**

**--> Panic mode --> Burn in function --> Permanent mode --> Broadcast control (button switch) --> Disable function --> Normal mode, Night mode, Staircase mode**

During the test mode or the burn in function, the control commands in Broadcast, Permanent, Normal, Night, Staircase and other modes will not be recorded (the Broadcast and Permanent mode are similar). However, the command of Disable function will be recorded. After exiting the high priority, the action of Disable function will be executed.

The higher-priority mode will override the status of the lower-priority mode, and exiting a high-priority mode will return to the lower priority mode.

During the disabled period, telegrams of low-priority are not recorded.

Test mode will interrupt the burn in function. After the exiting test mode, the burn in function needs to be restarted via the object.

If the test mode was previously in permanent mode, exit the test mode and return to permanent mode.

**2.When a DALI device is assigned to group control, it is not recommended for independent control. The main purpose is to avoid the conflict between the single device control mode and the group control mode.**

3. The operation mode of the ECG has a lower priority than the group control operation mode. If the ECG is assigned to the group, its operation mode will be executed independently. However, once the ECG is assigned to a group, its operation mode will be determined by the group's operation mode. In cases where the ECG belongs to multiple groups, the operation mode of the ECG will be based on the group numbers, starting from the smallest to the largest.

#### **4.2.8. Operation hour calculation**

The gateway provides an operation time recording function for each lamp, unit in hours, as long as the brightness value is >0% and recorded, and the recorded operation time can also be reset by the object. It is recommended to configure a maximum for each ECG based on the life of the lamp and activate the alarm object to facilitate maintenance when comes to the end life of the lamp.

In order to learn about the life of the lamp, many lamps will undergo a burn-in test when firstly used. During the burn-in phase, the lamps cannot be turned off or dimmed, but run at 100% brightness. Therefore, the gateway is equipped with a burn-in function for each ECG and group, and each ECG or each group can activate the burn-in mode through the object. During burn-in, the ECG or group can no longer be controlled separately. If the gateway power off during burn-in, the burn-in mode does not continue after the power supply recovery. It needs to be restarted by the object. When the burn-in mode is normally stopped (if the burn-in time is completed or turned off by the object), the device will return to the on or off value, or the previous brightness value, depending on the parameter settings, and can be controlled separately.

#### **4.2.9. ECG Failure or Lamp Failure Identification**

A major advantage of DALI technology is the ability to individually identify lamp failures or ECG failures. Therefore, the gateway supports this function and offers a variety of analysis possibilities. In order to analysis, the gateway periodically scans all connected ECGs for ECG failures and lamp failures. The scan time can be configured via parameters. For example, if the time is set to 1s (standard setting) and 64 ECGs are connected, the complete process of scanning ECG and lamp failures takes 64s (each ECG and fault type is 1s), so it may be necessary to identify the failure before it occurs, it is probably about 1 minute. The failure scans of the two channels do not interfere with each other and can be executed simultaneously. The identified fault information can be sent to the KNX bus via the ECG's fault object (2byte, 1 byte or 1 bit). In addition, the failure status of all ECGs can also be viewed via the DCA tool, or the failure status of each ECG and lamp can be queried via object 7.

**Note: Database version of 2.0 or above and DCA versions of 2.0.0.1 or above also support to identify converter failures.**

#### **4.2.10. Device Failures Number and Failure Rate Analysis**

On the entire DALI bus, according to the type of equipment failure, it is divided into ECG and lamp failure. The gateway sets the alarm settings for the fault rate for each type of failure, and can obtain their number of failures or failure rates through the communication objects, as well as the number of failures or failure rates in the entire DALI segment. In addition, the DCA tool can also be used to view the number of failures and failure rates for each fault type, as well as the total number of failures and the total failure rate (all ECGs and lamps).

**Note: Database version of 2.0 or above and DCA versions of 2.0.0.1 or above also support to view the number of failures and failure rates for converter.**

#### 4.2.11. Colour Temperature Adjustment

The colour temperature determines the lamp colour of the lamp, and the colour temperature unit is Kelvin (K). The group control of this gateway supports colour temperature adjustment.

Known Kelvin values for lamp colours:

1500 K - candle

2700 K - incandescent lamp (60W)

2800 K - halogen lamp

4000 K - fluorescent lamp (natural white)

The table below lists common colour temperatures and describes the lighting atmosphere and the scenes that are commonly used.

colour temperature	colour	Atmosphere	Scenes
2700 K	Warm White	Comfortable and warm	Living room, bedroom
3000 K	Bright and warm white	Warm, slightly brighter than warm white	Living space, restaurant
3500 K	Natural white	Objective and friendly	Corridor, office, showroom
4000 K	Natural white	Bright	Bathroom, kitchen, basement, garage
5300 K above	Daylight white	Similar to daylight, the blue ratio is very high	Industrial area, classroom

**Note:** When selecting lamps that support DALI colour temperature or colour adjustment, pay attention to the type of lamps. There are two types of DT6 and DT8 commonly used on the market, and their control methods are different. DT6 needs to occupy two DALI addresses, while DT8 occupies one DALI address. If two DALI addresses is used to control a lamp, the number of lamps that can be controlled on the DALI bus will be reduced by half.

#### **4.2.12. RGB(W) adjustment**

Principally, one colour can be created by mixing different single colours (RGB or RGBW). Therefore, a colour can also be displayed according to the mixing ratio of different monochromes (eg, 50% red, 0% green, 60% blue).

But the colour defined in this case is not accurate, but depends to a large extent on the physical properties (wavelength, intensity) of the LED that produces colour. Nevertheless, indications of primary colour percentages in a system are useful for relative description of a colour.

DT-8 ballasts can be coloured via 3byte object (RGB) or 6byte object (RGBW). According to DALI standard EN 62386-209, up to six colours (RGBWAF) can be drawn. However, DALI-2 gateway only supports up to 4 colours, which is currently commonly used ECG type on the market.


**Note: In the KNX system, adjusting the RGB(W) value will change the lamp brightness at the same time; in the DALI system, adjusting the RGB(W) value only changes the color and does not affect the lamp brightness, which is determined by the power brightness value; there are differences between these two, so in order to ensure that the change of the RGB(W) adjusted brightness in the KNX can be properly executed by the DALI driver, this gateway splits the RGB(W) control telegram in KNX into two, the color value follows the value of the telegram in KNX, and the brightness value is equal to the V value in the HSV(W) corresponding to the RGB(W) telegram.**

**Based on the above logic, the following situations may exist:**

- 1. when the gateway receives a color control value, it sends two control commands, color value and brightness value to the DALI bus.**
- 2. When the gateway receives a brightness control value, it sends a brightness control command to the driver, but the feedback status is synchronized to update the RGB status.**
- 3. When the gateway receives a turn on the lamp control command at the same time, it will default to the color of the lamp (by the parameter "Colour value when switch on") or the previous color and the corresponding brightness.**
- 4. The preset brightness and color in the group scene or global scene are sent to the DALI system for execution, and the execution result may differ from the brightness value preset in KNX.**

#### 4.2.13. XY adjustment

It is a method to display colours via 2 specified coordinates in colour space (x-y coordinates). Any points in this space can be selected, so any colour can be defined.



In devices that support the x-y coordinate method, the colour is set via two values between 0 and 1.00. However, due to the physical properties of LEDs, it is impossible to actually implement all colours even in an RGB LED module. In actual use, the closest value is usually set.

**Note:** x and y values should be set according to manufacturer's instructions of ECGs and lamps, if x and y values outside the specified range may result in incorrect values and unachievable colours.

#### 4.2.14. Motion and brightness sensor

DALI-2 gateway supports the configuration of 8 motion sensors with brightness sensors for per output channel.

With the DALI-2 gateway, DALI motion sensor can control devices via the KNX bus, e.g. by sending telegrams such as switches, scenes, brightness values, etc. to the KNX actuators via the KNX bus, which then execute the control. Or control with motion and brightness sensors.

**Note:** The DALI-2 gateway only supports motion sensors and brightness sensors according DALI IEC 63286 Part 303/304.



### 4.3. Operation Steps

This chapter mainly introduces the operation flow and precautions of DALI bus commission through DCA. The following steps are required for a newly installed project or a rectified project:

1.Ensure that the ETS running on the computer is the version with the license certificate (the available ETS dongle has been installed), and the DCA .etsapp file is correctly installed into the ETS.

2.Power on the device and wait for initialization to complete. Trigger broadcast switch control by short-pressing the Test/Set button to test if any DALI devices are not connected properly.

**Note:** When the device is powered on again, it will automatically perform initialization, reading the status of devices on the DALI bus. This process requires some time, which is related to the number of devices connecting to the DALI bus, and generally takes at least 30 seconds.

3.Parameter configuration of the device through the ETS software, and download the configured parameters to the gateway.

**Note:** ①ECG devices in the ETS are by default matched to driver addresses on the DALI bus, and the association can be modified through DCA.

② DCA uses point-to-point communication and shares a bus interface with device debugging. Therefore, when downloading databases or diagnosing devices, the DCA connection must be disconnected first, otherwise it will result in "Download(Appl.) failure" or "Device exists, but failed to connect". As shown in Fig. 4.3(1) and Fig.4.3(2):



Fig.4.3(1) Download(Appl.) failure

Check if an address is reachable and locate the device




Fig.4.3(2) Device exists, but failed to connect

③ After the database is downloaded, the gateway will perform a restart operation and automatically initialize, reading the status of devices on the DALI bus. This process requires some time, which is related to the number of devices connecting to the DALI bus, and generally takes at

**least 30 seconds.**

4. Enter the DCA editing interface, select commission channel and read the device status.

5. Initialization operation, click “[All] init DALI device” or “[No Addr] init DALI device” to reassign addresses to the drivers on the DALI bus to ensure that each driver has a unique address.

6. Sync. DaliBus and obtain the DALI device list: Use the DCA tool to read the driver status.

7. Obtain the ECG list: Click “Synchronize ETS data” to obtain the list of ECGs configured in the ETS.

**Note: If there is no database source file, you can click “Sync. Gateway” to read the list of ECG and**

**DALI drivers cached by the gateway.**

8. Modify the correlation between ECG and DALI driver and download it to the gateway.

There are 2 ways to modify:

① Drag the grid to associate the ECG to the specified driver address.

② By right-clicking on the device grid and select “Modify Address” .

**Note: In this step, you need to make sure that the ECG type is the same as the driver type of the corresponding address; if not, DCA will report an error.**

9. DALI driver information configuration: By double-clicking the device grid with the left mouse button to enter the driver detail configuration page, you can modify the driver parameter configuration, such as device configuration, scene configuration, etc.

**Note: The driver configuration information will only take effect after it is load on the configuration page, otherwise, it will be invalid.**

10. After performing the above steps, click “Sync. Gateway” to read the data in the gateway and check whether the sent data is correct.

**If you do not follow the above steps, the DALI device may not perform the operation according to the preset brightness value.**

**Note: In the address allocation phase, if there is an incomplete allocation address, start the initialization without address allocation operation (by DCA tool). If address allocation still fail more than twice, then you need to start the DALI bus initialization operation (by DCA tool or long press the Test/set button on the KNX-DALI-2 Gateway for more than 5 seconds), this operation may cause the DALI device addressed to occur change, you need to check the correspondence between the ECG and the driver address after configuration to ensure that the device type set by the ECG needs to be the same as the type of the actual driver, otherwise some of the functions will not be controlled.**

11. Export configuration, save the configuration of the gateway.

## Chapter 5 Parameter Setting Description in the ETS

### 5.1. KNX Secure

KNX-DALI-2 Gateway, 1/2-Fold is a KNX device that complies with the KNX secure standard. That is, you can run the device in safe way.



Fig.5.1 (1) "KNX Secure" parameter window

The device with KNX secure will be displayed notes on ETS, as shown as Fig.5.1(1).

If secure commissioning is activated in ETS project, the following information must be considered during device debugging:



❖ If secure commissioning is activated in ETS project and the DCA is connected, control commands cannot be sent to the DALI-2 gateway in ETS, but control commands from other devices on the KNX bus can still be sent to the DALI-2 gateway. This is because there is a problem with the ETS connection, which makes it impossible to use ETS for diagnosing and controlling the gateway.

❖ It is essential to assign a project password as soon as a KNX Secure device is imported into a project. This will protect the project against unauthorized access.

**The password must be kept in a safe place – access to the project is not possible without it (not even the KNX Association or device manufacturer will be able to access it)!**

**Without the project password, the commissioning key will not be able to be imported.**

❖ A commissioning key is required when commissioning a KNX Secure device (first download). This key (FDSK = Factory Default Setup Key) is included on a sticker on the side of the device, and it

must be imported into the ETS prior to the first download:

✧ When first download of the device, a window pops up in the ETS to prompt the user to enter the key, as shown in Fig.5.1 (2) below.

The certificate can also be read from the device using a QR scanner (recommended).




Fig.5.1(2) Add Device Certificate window

✧ Alternatively, the certificates of all Secure devices can be entered in the ETS beforehand.

This is done on the "Security" tab on the project overview page, as shown in Fig.5.1(3) below.

The certificates can be also added to the selected device in the project, as shown in Fig.5.1(4).




Fig.5.1(3) Add Device Certificate




Fig.5.1(4) Add Device Certificate

- ✧ There is a FDSK sticker on the device, which is used for viewing FDSK number.

**Without the FDSK, it will no longer be possible to operate the device in KNX Secure mode after a reset.**

The FDSK is required only for initial commissioning. After entering the initial FDSK, the ETS will assign a new key, as shown in Fig.5.1(5) below.

The FDSK will be required again only if the device was reset to its factory settings (e.g. If the device is to be used in a different ETS project).




Fig.5.1(5)

Example:

If this application in the project needs to be tried with another device, it is no longer the original device. When the application is downloaded to a new device, the following prompt will appear on the left of Fig.5.1(6), click yes, the Add Device Certificate window will appear, then enter the initial FDSK of the new device, and you need to reset the device to the factory settings (it is not required if the device is still factory default; If it has been used, it will be required to reset, otherwise the following error message will appear on the right of Fig.5.1(6)), and then the device can be successfully downloaded again.




Fig.5.1(6) Example

Whether the device is replaced in the same project, or the device is replaced in a different

project, the processing is similar: **Reset the device to the factory settings, then reassign the FDSK.**

After the device is downloaded successfully, the label Add Device Certificate turns gray, indicating that the key for this device has been assigned successfully, as shown in Fig.5.1(7) below.




Fig.5.1(7)

ETS generates and manages keys:

Keys and passwords can be exported as needed to the use of security keys outside of the associated ETS projects. As shown in Fig.5.1(8) below, the file extension is .knxkeys.




Fig.5.1(8)

**Note: Any USB interface used for programming a KNX Secure device must support "long frames".**

**Otherwise ETS will report a download failure information, as shown below.**



Fig.5.1(9)

## 5.2. Parameter window "General"

Parameter setting interface "General" as shown in Figure 5.2, the configured basic parameters are valid for all DALI devices of the gateway.

The parameter configuration and functions are the same whether it is 1-Fold or 2-Fold. The following section will take 2-Fold as an example.

Fig.5.2 Parameter window "General"

### Parameter "Device Name(max.30 char)"

This parameter is used to input the device name (up to 30 characters).

### Parameter "Send delay after KNX bus recovery"

This parameter defines the time delay for sending status telegrams after the bus recovery reset. Only when the delay complete can the device send status telegrams to the bus. In a project with multiple gateways installed, different settings for this parameter can prevent all devices from sending status telegrams at the same time. Options:

**Immediately**

**5s**

**10s**

**...**

**60s**

This delay time does not include the initialization time of the device. This delay begins when the device is initialized.

After the bus voltage is recovery, the initialization time of the device startup increases with the increase of the connected DALI device. When the device is connected to 128 ECGs, the device startup



initialization time will be completed within 2 minutes (excluding initialization time of KNX DALI gateway).

**Note: This parameter only affects the status telegrams sent to the bus, and does not affect the operation executed. The operation is completed and may be executed after the device is initialized.**

Parameter "Send cycle "In operation" telegram (1...240, 0=inactive)"

This parameter sets the interval at which the device periodically sends a telegram through the bus to indicate that the device application layer is operating normally. When set to "0", the object "In operation" will not send a telegram. If the setting is not "0", the object "In operation" will send a telegram with logic "1" to the bus for the set time period. Options: **0...240s, 0=inactive**

The cyclic telegram is monitored by the external device. If the external device does not receive the telegram within the monitoring time, the device is considered to be faulty or the bus transmission is interrupted. In order to reduce the bus load as much as possible, the maximum time interval should be selected according to actual needs.

**Note: The time interval is counted from the completion of the device initialization, regardless of the bus power-on delay transmission.**

Parameter "Send delay between DALI status objects"

This parameter defines the delay between sending DALI status telegrams, that is, the interval between each status telegram transmission, which can prevent excessive bus load, for example, broadcast switch control. Options:

**No delay**

**0.5s**

**1s**

**2s**

**...**

**10s**

All status telegrams sent to the bus are affected by this parameter setting, such as switch status, brightness status, DALI failure status, and so on.

Parameter "Cycle time for DALI status requests"

This parameter sets the time period for sending DALI device (brightness, failure) request. In order



to analyze ECG and lamp failures, and to figure out the actual brightness status of the lamp, failure request telegram and brightness query telegram must be sent periodically to the ECG on the DALI bus.

Options:

**No request**

**0.5s**

**1s**

**2s**

**...**

**10s**

For example, if it is set to 1s and 64 ECGs are connected, the complete process of scanning the ECG and the lamp takes 64s (each ECG and failure type is 1s), so it may take about 1 minute before identifying that a failure occurs.

This setting mainly affects the DALI bus, where a longer cycle can reduce the bus load. However, it may not be possible to immediately detect faults on DALI devices. Similarly, detecting new devices or recovering devices also takes longer.

**Note: If “No request” is set, the gateway will not request ECGs’ status, that is, the gateway will not recognize the ECG and lamp failure or actual working status, so it is recommended to select this option in special cases.**

Parameter “Normal(day)/Night mode”

This parameter for setting object value of normal/night mode. Options:

**Normal=0/Night=1**

**Normal=1/Night=0**

**Note: This function is associated with driving the opening brightness value. Different brightness values can be set for normal and night. It affects the execution of the ECG's night control mode. If it is normal mode, the gateway does not execute the night mode of the ECG/group.**

### 5.3. Parameter window "DALI Output A/B"

This interface mainly sets the general parameters of the DALI device in the channel, such as KNX bus failure or reset action, status transmission mode, failure report and failure analysis. The parameters of the two channels are the same as the objects. The following is an example of one of the channels.

Enable automatic DALI addressing	<input type="checkbox"/>
Test/Set button function via long press (>5s)	Init all device ▼
Reply mode of Lamp status	Respond on change ▼
Action after Burn In	Off value ▼
Action after Panic mode	Off value ▼
Action after Test mode for central battery emergency lights	Off value ▼
Converter inhibit mode for self-contained battery emergency lights	<input type="checkbox"/>
<hr/>	
Object "Read DALI bus voltage"	<input type="checkbox"/>
Object "Read DALI bus current"	<input type="checkbox"/>
<hr/>	
Overwrite group assignment of ECGs after download	<input type="checkbox"/>
Overwrite the configuration of ECGs after download	<input type="checkbox"/>
Overwrite DALI scene of ECGs after download	<input type="checkbox"/>
<hr/>	
Apply DCA setting for all ECGs	No, independent setting in each ECGs ▼
<hr/>	
<b>Failure analysis</b>	
Reply mode of failure status	Respond on change ▼
Failure object "DALI short circuit"	<input type="checkbox"/>
Failure object "DALI power supply"	<input type="checkbox"/>
Failure object "General failure"	<input type="checkbox"/>
Failure object "Lamp/ECG Failure status"	<input type="checkbox"/>
<hr/>	
Function of failure object	<input checked="" type="radio"/> Total number of failures <input type="radio"/> Failure rate 0..100%

Threshold for Total failures[1..100]	1	%
Threshold for Lamp failures[1..100]	1	%
Threshold for ECG failures[1..100]	1	%
Threshold for Converter failures[1..100]	1	%
<hr/>		
Broadcast control function	<input checked="" type="checkbox"/>	
Dimming curve	<input checked="" type="radio"/> Logarithmic(DALI) <input type="radio"/> Linear(KNX)	
Colour control type	None	
Dimming time for switching	2	s
Dimming time for brightness	2	s

Fig.5.3 Parameter window“DALI Output A/B”

#### Parameter “Enable automatic DALI addressing”

This parameter sets whether a DALI device without a DALI address is automatically initialized after the gateway supply voltage recovery or reset, that is, whether the gateway automatically assigns the first free DALI address to it.

**Disable:** The gateway does not assign DALI addresses on gateway supply voltage recovery. If a DALI device without an address has been installed, the gateway can only control it using a broadcast telegram. If a DALI device with an existing address has been installed, the gateway will not change it. **(The DALI address can still be assigned via DCA tool or the Test/Set button on the front of the gateway).**

**Enable:** If the gateway locates a DALI device without a DALI address after supply voltage recovery, the gateway automatically allocates it the first free DALI address.

It is advantage that DALI addressing without gaps makes it possible to replace a defective DALI device without additional addressing or commissioning. All that is required is to connect a DALI device without address. The gateway addresses the new device with the first free DALI address of the removed failed device, and transfers its properties to the new device.

#### Parameter “Test/Set button function via long press(>5s)”

The parameter sets the function of the Test/Set button, and it need be executed via a long operation that press the button longer than 5s. Options:

**No action**

**Init no address device**

**Init all device**

No action: It is no action.

Init no address device: The gateway can initialize the DALI devices without a DALI address on the DALI bus via long press the button >5s.

Init all device: The gateway can reinitialize all DALI devices on the DALI bus via long press the button >5s.

#### Parameter "Reply mode of Lamp status"

This parameter defines the feedback conditions of lamp status when under the group and ECG control, that is, the feedback conditions for the switch status and brightness status. Options:

**Respond after read only**

**Respond after change**

**Respond after change and bus reset**

Respond after read only: Only when the device receives a request from another bus device or bus to read the switch status or brightness status of the group or ECG, does the status object send the current switch or brightness status to the bus.

Respond after change: When the switch status or brightness status changes, the status object sends a telegram to the bus to report the current status.

Respond after change and bus reset: When the switch status, brightness status changes or bus reset, the status object sends a telegram to the bus to report the current status.

**Note: The switch status and brightness status of the group can only be feedback locally, and the status of each lamp cannot be accurately fed back. Therefore, it is recommended to use ECG status feedback.**

#### Parameter "Action after Burn In"

This parameter defines the brightness value of the ECG/lamp after burnt in. Options:

**On value**

**Off value**

**Last brightness value**

On value: Outputs the brightness value of "Switch on".

Off value: The outputs are off.

Last brightness value: The brightness value of the ECG/lamp will be saved before burnt in. After the burn in is completed, the ECG/lamp returns to the previous brightness value.

#### Parameter "Action after panic mode"

This parameter defines the brightness value of the ECG/lamp after panic mode. Options:

**On value**

**Off value**

**Last brightness value**

On value: Outputs the brightness value of "Switch on".

Off value: The outputs are off.

Last brightness value: The brightness value of the ECG/lamp will be saved before panic mode. After the panic mode is completed, the ECG/lamp returns to the previous brightness value.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### Parameter "Action after test mode for central battery emergency lights"

This parameter defines the brightness value of the ECG/lamp after test mode for central battery emergency lights. Options:

**On value**

**Off value**

**Last brightness value**

On value: Outputs the brightness value of "Switch on".

Off value: The outputs are off.

Last brightness value: The brightness value of the ECG/lamp will be saved before test mode. After the test mode is completed, the ECG/lamp returns to the previous brightness value.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### Parameter "Converter inhibit mode for self-contained battery emergency lights"

This parameter sets whether to enable the function of converter inhibit mode for self-contained

battery emergency lights.

If there is a power supply failure, self-contained battery emergency lights always change to emergency mode. The lamp is now powered by internal battery. However, during commissioning and installation, it may be necessary to cut off the power to prevent continuous emergency lighting and battery discharge.

Enable this parameter to prevent lamps from switching to emergency mode. Once enabled, the DALI-2 gateway sends an inhibit telegram via "Converter inhibit mode". Drivers turn off all emergency lights in channel within 15 minutes after receiving command, does not switch to emergency mode. After power recovery, lamps return to normal mode. If there is no power supply failure in 15 minutes, converters reset to normal mode.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

Parameter "Object "Read DALI bus voltage"

This parameter sets whether to enable the object for reading the DALI bus voltage, responding only to the DALI bus voltage status when read.

Parameter "Object "Read DALI bus current"

This parameter sets whether to enable the object for reading the DALI bus current, responding only to the DALI bus current status when read.

Parameter "Overwrite group assignment of ECGs after download"

This parameter sets whether to overwrite group assignment of ECGs after download. When enable, the group assignment saved in the gateway will be sent to all ECGs after download, this function is mainly used in the replacement of failure ECGs.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

Parameter "Overwrite the configuration of ECGs after download"

This parameter sets whether to overwrite the configuration of ECGs after download. When enable, the configuration of ECGs saved in the gateway will be sent to all ECGs after download, this function is mainly used in the replacement of failure ECGs.

When enable, note:

**i** In this case, it depends on the selection of parameter "Apply DCA setting for ECG". If No, the gateway will overwrite the ECGs with ETS settings after download; if Yes, the gateway will overwrite the ECGs with stored DCA settings after download.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### Parameter "Overwrite DALI scene of ECGs after download"

This parameter sets whether to overwrite DALI scene of ECGs after download. When enable, the DALI scenes saved in the gateway will be sent to all ECGs after download; this function is mainly used in the replacement of failure ECGs.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

**Any of the above 3 parameters enable, note:**

**i** The above 3 parameters are mainly used to replace the ECGs, and will extend the initial time when the above parameters enable; please check.

#### Parameter "Apply DCA setting for all ECGs"

This parameter sets whether to apply DCA setting for all ECGs. Options:

**No, ETS parameter setting to all ECGs**

**No, independent setting in each ECGs**

**Yes**

No, ETS parameter setting to all ECGs: no DCA setting applies for ECGs and the parameter "Apply DCA setting for ECG" in each ECGs is only read to disable.

No, independent setting in each ECGs: DCA setting does not apply for all ECGs; it needs to configure the parameter "Apply DCA setting for ECG" separately in each ECGs.

Yes: DCA setting applies for all ECGs and the parameter "Apply DCA setting for ECG" in each ECGs is only read to disable.

**Note: This function is only suitable for versions with database versions of 2.0 or above.**

## Failure analysis

### Parameter "Reply mode of failure status"

This parameter defines the conditions for sending ECG and lamp failure conditions. Options:

**Respond after read only**

**Respond after change**

**Respond after change and bus reset**

Respond after read only: Only when the device receives a request to read the fault status from another bus device or ECG/Group, the status object send the current failure status to the bus.

Respond after change: When the failure status changes, the status object sends a telegram to the bus to report the current status.

Respond after change and bus reset: When the failure status changes or bus reset, the status object sends a telegram to the bus to report the current status.

### Parameter "Failure object "DALI short circuit""

This parameter is used to report whether a short circuit is present on the connected DALI bus.

### Parameter "Failure object "DALI power supply""

This parameter is used to report whether there is an failure in the power supply of the DALI bus.

### Parameter "Failure object "General failure""

This parameter is used to report faults on the DALI bus channel. In case of any type of fault occurrence, the object will send a telegram "1" on the bus, and send "0" when the fault is cleared. For example, ECG, lamp faults.

### Parameter "Failure object "Lamp/ECG Failure status""

This parameter sets whether the object for the channel ECG/lamp failure centrally send status is enabled.

Enable: The object "Lamp/ECG Failure status" is visible and is used to send the lamp or ECG failure status. The 1 byte object value is defined as follows:



Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
ECG failure	Lamp failure	ECG number1..64					

example:

1. 1000 0011 (object value 131) indicates ECG failure of ECG4.

0100 0010 (object value 66) indicates lamp failure of ECG3.

This object can also be used to query the lamp and ECG failure. When the highest two bit value, both Bit7 and Bit6, of the telegram received by the object are 1, indicating to query the ECG x failure, such as:

Query the failure status of ECG3: 1100 0010 (object value 194)

If the ECG of ECG3 is faulty, the gateway will respond: 1000 0010 (object value 130)

**Lamp failure: One or more fixtures does not working (damaged) or are not connected.**

**ECG failure: One or more ballasts on the output of the DALI gateway do not work or are not connected.**

#### Parameter "Function of failure object"

This parameter sets the transmission mode of the lamp and ECG failure, whether to send by the ratio of the faulty device or the number of faulty devices. In different ways, the data types of the failure objects 7, 9, and 11 are also different. Options:

#### **Total number of failures**

#### **Failure rate 0..100%**

Total number of failures: The number of faulty devices sent directly by the object to the bus.

Failure rate 0..100%: The failure rate of the faulty device in the total number of devices that is sent to the bus by the objects.

For example, if there are 8 lamps and 1 failure, then the lamp failure rate is 12%.

#### Parameter "Threshold for Total failures[1...100]"

This parameter is used to configure the alarm threshold for all (ECG and lamp) failures (object 8) in the channel. The threshold relates to the failure of all ECGs and lamps at the DALI end of the channel, and when the total number of failures exceeds the set threshold, the object 8 sends an alarm. Options:

**1..100%**

**Parameter "Threshold for Lamp failures[1...100]"**

This parameter is used to configure the alarm threshold for all lamp failures (object 10) of the channel. The threshold relates to the failure of all the lamps at the DALI end of the channel, and when the total number of failures exceeds the set threshold, the object 10 sends an alarm. Options: **1..100%**

**Parameter "Threshold for ECG failures[1...100]"**

This parameter is used to configure the alarm threshold for all ECG failures (object 12) of the channel. The threshold relates to the failure of all ECGs at the DALI end of the channel, and when the total number of failures exceeds the set threshold, the object 12 sends an alarm. Options: **1..100%**

**Parameter "Threshold for converter failures[1...100]"**

This parameter is used to configure the alarm threshold for all converter failures (object 17) of the channel. The threshold relates to the failure of all converts at the DALI end of the channel, and when the total number of failures exceeds the set threshold, the object 17 sends an alarm. Options: **1..100%**

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

**Parameter "Broadcast control function"**

This parameter is used to set whether to enable the broadcast control function.

Broadcast control applies to all devices on that channel, allowing them to receive DALI broadcast control even if they are not individually addressed.

**When the broadcast control function is enabled, the following parameters are visible:**

**--Parameter "Dimming curve "**


This parameter sets the dimming curve for the Broadcast control. Options:

**Logarithmic(DALI)**

**Linear(KNX)**

In the KNX to DALI, by default, all lamps use a logarithmic dimming curve. However, this product also provides a linear dimming curve, achieved through the gateway's own fitting adjustment process to produce a linear dimming effect.

The logarithmic(DALI) and linear (KNX) dimming curves as shown in the following figure:



In the KNX to DALI, the ballast curve is set by default to a logarithmic dimming curve. Unless necessary, please do not modify the dimming curve, as changing the dimming curve settings may cause issues with the aforementioned dimming curve settings.

#### --Parameter "Colour control type"

This parameter is used to set the type of broadcast colour control. Only devices that support this control type will respond. Options:

**None**

**Colour Temperature**

**RGB Colour**

**RGBW Colour**

**XY Colour**

Colour Temperature: Cool-warm colour control.

RGB Colour: Three RGB colour controls.

RGBW Colour: Four RGBW colour controls.

XY Colour: It is a method of controlling colour in colour space through two specified coordinates.

#### --Parameter "Object type for RGB Colour"

This parameter is visible when "RGB Colour" is selected, used to set the object type for RGB colour control. Options:

**RGB(Combined object)**

**HSV(Separated objects)**

**H, S, V represent the hue, saturation, brightness (brightness value adjustment) respectively**

**--Parameter "Object type for RGBW Colour"**

This parameter is visible when "RGBW Colour" is selected, used to set the object type for RGBW colour control. Options:

**RGBW(Combined object)**

**HSVW(Separated objects)**

**--Parameter "Object type for XY Colour"**

This parameter is visible when "XY Colour" is selected, used to set the object type for XY colour control. Options:

**XY(Combined object)**

**XY(Separated objects)**

**Note: When broadcast control switch is turned on, the device status is the colour value before last switch off.**

**Broadcast control "switch on" defaults to 100% brightness when turned on and 0% when turned off.**

**When the connected ECG is in a special mode, such as burn-in mode, the ECG cannot be controlled through broadcast "Switch" and "Brightness dimming" objects, but the colour can be adjusted.**

**--Parameter "Dimming time for switching"**

This parameter is used to define the dimming time for switch status changes during broadcasting.

Options: **0...255s**

**--Parameter "Dimming time for brightness"**

This parameter is used to define the total dimming time for brightness during broadcast control.

Options: **0...255s**

#### 5.4. Parameter window "ECG/Group Template setting"





Fig.5.4 Parameter window "ECG/Group Template setting"

##### Parameter "Number of templates"

This parameter is used to set the number of parameter setting templates for ECG and group operations, up to 8.

##### 5.4.1. Parameter window "Template X(X=1~8)"

Parameter setting interface "Template X" is shown in Figure 5.4.1. Here, the group control and ECG control action behaviors are set. A total of 8 parameter setting templates are provided. If the action of the group control and ECG control is as configuration of ECG, then the action behaviors will be configured by the DCA tool.



Description (max. 30 char)	<input type="text"/>	
Switch on value	100	%
Switch on value in night mode	100	%
Fade time	0.7	s
Value on DALI power fail (DALI System Failure Level)	Unchange	%
Value on ECG power recovery (DALI Power On Level)	Value before failure	%
Value on KNX bus voltage recovery and download	Unchange	%
Dimming time for switch on	2	s
Dimming time for switch off	2	s
Dimming time for brightness dimming	2	s
Dimming time for relative dimming	2	s

Minimum brightness value	1	%
Maximum brightness value	100	%
Allow switch off via relative dimming	<input checked="" type="radio"/> No (To the Min. brightness) <input type="radio"/> Yes	
Absolute dimming value lower than the minimum value	0%=0%, otherwise=Minimum brightness value	
Burn In function	<input checked="" type="checkbox"/>	
Burn In duration	100	h
Dimming curve	<input checked="" type="radio"/> Logarithmic(DALI) <input type="radio"/> Linear(KNX)	

Fig.5.4.1 Parameter window "Template X" (X=1~8)

**Take one of the templates as an example to illustrate the parameter settings:**

Parameter "Description (max.30 char)"

This parameter is used to input the parameter setting templates name (up to 30 characters).

Parameter "Switch on value"

This parameter defines the brightness value of "Switch on". Options:

1%

2%

...

100%

**Last brightness value**

Last brightness value: The value of the brightness before the lamp is turned off. Defaults to 50% when uncertain.

For ECG/Group, if there is a distinction between normal/night, this parameter sets the switching value for normal. Without differentiation, the switching value of this parameter is used regardless of normal/night.

Parameter "Switch on value in night mode"

This parameter defines the brightness value of "Switch on" in night mode. Options:

**Disable**

1%

2%

...

100%

**Last brightness value**

Disable: The brightness value is not differentiated between normal and night, so the brightness value used for switch on the lamps at night remains the same as during the normal.

Last brightness value: The value of the brightness before the lamp is turned off. Defaults to 10% when uncertain.

**Parameter "Fade time"**

This parameter sets the fade time of the DALI driver adjust brightness, colour temperature and colour. Options:

0s

0.7s

1.0s

1.4s

2.0s

...

90.5s

**Note:**

1. The recommended fade time is 0.7s.

2. The fade time must be shorter than the dimming time, otherwise, the dimming parameters (such as "Dimming time for switch on/switch off/brightness dimming/relative dimming") will be invalid.

**Parameter "Value on DALI power fail (DALI System Failure Level)"**

This parameter defines the brightness value of the lamp after the DALI bus is powered off. This value is saved in ECG, and ECG automatically changes the output of the brightness value in the event of power off. Options:

0%

1%

2%

...

100%

**Unchange**

Unchange: The output brightness value is the brightness value before DALI bus power off, that is, the lamp brightness does not change.

Parameter "Value on ECG power recovery (DALI Power On Level)"

This parameter defines the brightness value of the lamp after ECG power-on reset. This value will be saved in the ECG, and the ECG will output the brightness value when the ECG is powered on and reset. Options:

0%

1%

2%

...

100%

**Value before failure**

Value before failure: The output brightness value is the brightness value before the ECG is power recovery.

Parameter "Value on KNX bus voltage recovery and download "

This parameter defines the brightness value of the KNX bus voltage recovery and download.

Options:

0%

1%

2%

...

100%

**Unchange**

**Value before failure**

Unchange: The brightness does not change and remains current.



Value before failure: The brightness returns to the state before KNX bus voltage failure. To ensure that the brightness is restored after the KNX bus voltage recovers, the brightness value must be set for at least two seconds before the KNX voltage failure or download (otherwise, there may be fail to saving). Regarding the download, it refers to the brightness value before the download.

Parameter "Dimming time for switch on/off"

This parameter defines the dimming time of the lamp brightness. That is, the dimming time of the brightness from 0% to 100% or 100% to 0%. Options: **0...255s**

Parameter "Dimming time for brightness dimming"

This parameter defines the dimming time for brightness dimming. Options: **0...255s**

Parameter "Dimming time for relative dimming"

This parameter defines the dimming time for relative dimming. Options: **1...255s**

Parameter "Minimum brightness value"

This parameter defines the minimum control brightness value of the lamp, which refers to the minimum brightness value controllable by the KNX-DALI-2 Gateway for lamps. Options:

**0%**  
**1%**  
**2%**  
**...**  
**49%**

Parameter "Maximum brightness value"

This parameter defines the maximum control brightness value of the lamp, which refers to the maximum brightness value controllable by the KNX-DALI-2 Gateway for lamps. Options:

**50%**  
**51%**  
**52%**  
**...**  
**100%**

**Note: Any control command with brightness is limited to the minimum and maximum brightness value output.**

**Parameter "Allow switch off via relative dimming"**

This parameter defines whether to allow the lamp to be switched off by relative dimming .

Options:

**No(To the Min.brightness)**

**Yes**

No(To the Min.brightness): No allow, only dim down to minimum brightness.

Yes: When the brightness is dim down to the minimum brightness value, the lamp is turned off directly.

**Parameter "Absolute dimming value lower than the minimum value"**

This parameter sets the behavior when the absolute dimming value lower than the minimum value.

Options:

**0%=0%, otherwise=Minimum brightness value**

**To be the minimum brightness value**

**To be 0%**

0%=0%, otherwise=Minimum brightness value: Output at the minimum brightness value. if it is 0%, the lamp is turned off.

To be the minimum brightness value: Output at the minimum value, even if it is 0%.

To be 0%: Turn off the lamp.

**Parameter "Burn In function"**

This parameter sets whether the burn in function is enabled. During burn in, the lamp burn in maximum brightness, and the ECG/group can no longer be controlled separately. If the gateway power off during burn in, the burn in mode will not continue when power recovery; it needs to be restarted through an object. When the burn in mode is stopped normally (such as when the burn in time is completed or turned off through an object), the device will switch on/off, or return to the previous brightness level, depending on the parameter settings, and can be controlled separately again.

**Note:** In burn in mode, the colour can be adjusted, triggered or exited through the burn in object of channel A/B.

### --Parameter "Burn In duration"

After the burn in function is enabled, this parameter is visible and is used to set the duration of the burn in phase of the DALI device. Options: **1...255h**

### Parameter "Dimming curve "


This parameter sets the dimming curve type that the DALI device operates on when this template is selected. Options:

**Logarithmic(DALI)**

**Linear(KNX)**

For example, if the current driver curve type is a logarithmic dimming curve, if logarithmic is selected, fitting will not to fitting.If linear dimming curve is selected here, the adjustment effect will be simulated as linear through fitting.

Similar to the dimming curves under broadcast control and will not be repeated here.



### 5.5. Parameter window "Emergency Template setting"

**Note:** This template setting is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.



Fig.5.5 Parameter window "Emergency Template setting"

#### Parameter "Number of templates"

This parameter is used to set the number of parameter setting templates for self-contained battery lamp, up to 8.

#### 5.5.1. Parameter window "Template X(X=1~8)"

Parameter setting interface "Template X" is shown in Figure 5.5.1. Here, the emergency lighting control action behaviors are set. A total of 8 parameter setting templates are provided.




Fig.5.5.1 Parameter window "Template X"(X=1~8)

**Take one of the templates as an example to illustrate the parameter settings:**

#### Parameter "Description (max.30 char)"

This parameter is used to input the parameter setting templates name (up to 30 characters).

#### Parameter "Brightness value in emergency mode"

This parameter defines the brightness value in emergency mode when power failure. This value also used for function test and duration test.

Options:

**1%**

**2%**

**...**

**100%**

The setting value is stored in the emergency lighting converter, so it is still available even if it is not connected to the gateway.

Parameter "Delay time for return to normal mode after power recovery"

This parameter sets the delay time for return to normal mode after power recovery.

Options: **0...127 min, 0 is no delay**

Parameter "Interval of long duration test (0=inactive)"

This parameter sets interval for the converter to execute duration test automatically, which is used for test the battery capacity of the emergency lighting.

Options: **0...52 week, 0 is not execute duration test**

Parameter "Interval of function test (0=inactive)"

This parameter sets interval for the converter to execute function test automatically. During the function test, the ECG usually turns on the light for a few seconds to test whether it can enter the emergency status normally.

Options: **0...30 day, 0 is not execute function test**

Parameter "Test execution timeout"

This parameter sets the timeout period for the converter to execute test, When the converter receives the test request, the test must be run within this time period, otherwise a timeout will occur. After it is timeout, this instruction will no longer be executed. Options: **0...255 day**

In the case of low battery, the converter may not be able to execute the requested test (function test, duration test) of emergency lighting immediately, and the converter will try to execute the test at a later time (the time set by this parameter). If set to 0, the timeout will occur after 15 minutes.

The status of the test of emergency lighting can be sent or queried via the object.

## 5.6. Parameter window“Group setting”



Fig.5.6 Parameter window“Group setting”

### Parameter “Number of groups”

This parameter is used to set the number of group, up to 8.

None

1

2

...

16

### 5.6.1. Parameter window“Group X”(X=1~16)

Parameter setting interface“X: Group” is shown in Figure5.6.1. Here is to setting the group control of the DALI device.

Each channel of KNX/DALI gateway provides 16 groups. We can group multiple DALI devices that we want to control together by DCA tool. Then the devices in this group can be switched, dimmed or set the brightness value at the same time. If the properties of the devices in the same group are different, the dimming effects of the DALI devices will be different.

**Note: After group control or global scene control, the gateway immediately send the “ON” status of corresponding devices to the KNX bus for “ON” command. However, the “OFF” status will only be sent after dimming behavior complete for “OFF” command.**




Fig.5.6.1 Parameter window“Group X”

### Parameter “Group description(max 30 char.)”

This parameter is used to describe the group and allows up to 30 characters to be entered.

**Parameter "Operation mode"**

This parameter sets the operating mode of the group. Options:

**Normal mode**

**Permanent mode**

**Normal/Night mode**

**Staircase mode**

Normal mode: Common switch control of the lamp, such as switching, dimming and setting the brightness value of the DALI device in the group.

Permanent mode: The DALI device in the group outputs with a fixed brightness value, the brightness cannot be switched or changed.

**Note: when permanent mode, the lamp turns on immediately and there is no dimming process.**

Normal/Night mode: Under the normal mode, the control is the same as the first option. After switching to night mode, the lamp can be turned off in a delay time after the lamp is turned on, or output with a fixed brightness value. Activate night mode via object 2.

**Note: This function is associated with Object 2 "Normal(day)/Night mode" , and will only execute the corresponding configuration in night mode.**

Staircase mode: Turn on the Staircase lighting and automatic turn off after delay time.

**Parameter "Group behaviour select"**

This parameter sets the behavior of the group, which is achieved by recalling the settings of the template. Options:

**Template 1**

...

**Template 8**

#### 5.6.1.1. Operation mode "Normal mode"

This section only describes the parameter settings under the normal mode.

Description (max. 30 char)	<input type="text"/>
Operation mode	Normal mode ▼
Group behaviour select	Template 1
Disable function	Disable=1/Enable=0 ▼
Behaviour on enable	Unchange ▼
Behaviour on disable	Unchange ▼
Colour control function	<input checked="" type="checkbox"/>
Group scene function	<input checked="" type="checkbox"/>

Fig.5.6.1.1 "Normal mode"

This same parameter will not be illustrated in next chapters, the usage is similar.

#### Parameter "Disable function"

This parameter sets the disable/enable control for the group. This function is not supported when "permanent mode" is selected. Options:

**Disable**

**Disable=1/Enable=0**

**Disable=0/Enable=1**

When enabled, the following parameters are visible.

#### --Parameter "Behaviour on enable"

This parameter sets the behavior when the group is enabled. Options:

**Unchange**

**Switch on**

**Switch off**

Unchange: The group output is unchange.

Switch on: The group output executes the switch on operation.

Switch off: The group output executes the switch off operation.

#### --Parameter "Behaviour on disable"



This parameter sets the behavior when the group is disabled. Options:

**Unchange**

**Switch on**

**Switch off**

Unchange: The group output is unchange.

Switch on: The group output executes the switch on operation.

Switch off: The group output executes the switch off operation.

Parameter "Colour control function"

This parameter sets whether to enable the colour control function. For details of the parameters when enabled, see [Section 5.6.2](#).

Parameter "Group scene function"

This parameter sets whether to enable the group scene function. For details of the parameters when enabled, see [Section 5.6.3](#).

#### 5.6.1.2. Operation mode "Normal/Night mode"

This section only describes the parameter settings under the normal/night mode.

Description (max. 30 char)	<input type="text"/>
Operation mode	Normal/Night mode ▼
Action in night mode	<input checked="" type="radio"/> Delay switch off automatically <input type="radio"/> Activate permanent mode and ignore teleg...
Automatic switch off after	5 min
Group behaviour select	Template 1
Disable function	Disable=1/Enable=0 ▼
Behaviour on enable	Unchange ▼
Behaviour on disable	Unchange ▼
Colour control function	<input checked="" type="checkbox"/>
Group scene function	<input checked="" type="checkbox"/>

Fig.5.6.1.2 "Norma/Night mode"

**Parameter "Action in night mode"**

This parameter sets the action behavior in night mode. Options:

**Delay switch off automatically**

**Activate permanent mode and ignore telegrams**

Delay switch off automatically: The lamp will be automatically turned off after a delay time when it is turned on. If the lamp is on before switching to the night mode, after switching, the lamp will be automatically turned off when reach to the delay time.

**Note: When switching to normal mode, the lamp status is maintained.**

Activate permanent mode and ignore telegram: Activates permanent mode and ignores the control telegram, i.e outputs with a fixed brightness value.

**Note: When switching to normal mode, the lamp status is maintained.**

**Parameter "Automatic switch off after"**

This parameter is visible when the previous parameter selects "Delay switch off automatically". Set the delay time for the DALI device in the group to automatically turn off the lamp.

Options: **1..255 min**

**Parameter "Brightness value in permanent mode"**

This parameter is visible when option "Activate permanent mode and ignore telegram" of the parameter "Action in night mode" is selected. Setting the output brightness value of the DALI device in the group when under the permanent mode. Options:

**0%**

**1%**

**...**

**100%**

### 5.6.1.3. Operation mode "Staircase mode"

This section only describes the parameter settings under the staircase mode.

Description (max. 30 char)	<input type="text"/>
Operation mode	Staircase mode ▼
Automatic switch off after	5 min
Group behaviour select	Template 1
<hr/>	
Disable function	Disable=1/Enable=0 ▼
Behaviour on enable	Unchange ▼
Behaviour on disable	Unchange ▼
<hr/>	
Colour control function	<input checked="" type="checkbox"/>
Group scene function	<input checked="" type="checkbox"/>

Fig.5.6.1.3 "Staircase mode"

#### Parameter "Automatic switch off after"

This parameter setting the delay time to automatically turn off the lamp after DALI device in the group is turned on. Options: **1..255 min**

#### 5.6.1.4. Operation mode "Permanent mode"

This section only describes the parameter settings under the permanent mode.

Description (max. 30 char)	<input type="text"/>
Operation mode	Permanent mode ▼
Brightness value in permanent mode	50 ▼ %
Group behaviour select	Template 1
<hr/>	
Colour control function	<input checked="" type="checkbox"/>
Group scene function	<input checked="" type="checkbox"/>

Fig.5.6.1.4 "Permanent mode"

#### Parameter "Brightness value in Permanent mode"

This parameter sets the brightness value of the DALI device output in the group under the permanent mode. Options:

0%  
1%  
...  
100%

### 5.6.2. Parameter window "Colour control"

This interface is visible when "Colour control function" is enabled.



Fig.5.6.2 "Colour control"

#### Parameter "Colour control type"

This parameter sets the colour control type for the group. Options:

**Colour Temperature**

**RGB Colour**

**RGBW Colour**

**XY Colour**

Colour Temperature: Cool-warm colour control.

RGB Colour: RGB colour controls.

RGBW Colour: RGBW colour controls.

XY Colour: It is a method of controlling colour in colour space through two specified coordinates.

**Note:** The colour type of the group is required to be the same as the colour type set by the ECG in the group, otherwise control errors may occur.

## 5.6.2.1. Colour control type "Colour Temperature"

Colour control type	Colour Temperature
Object datatype of colour temperature	<input type="radio"/> 1byte relative percentage value <input checked="" type="radio"/> 2byte absolute value
Behaviour when switch on	<input checked="" type="radio"/> Via ETS parameter <input type="radio"/> Last colour temperature value
Colour temperature when switch on	3000 K
Minimum colour temperature control	2700 K
Maximum colour temperature control	6500 K
Dimming time via colour relative dimming	2 s
Allow switch on via relative dimming	<input type="checkbox"/>
Allow switch on via set colour temperature	<input checked="" type="checkbox"/>
Allow switch on via colour relative dimming	<input checked="" type="checkbox"/>

Fig.5.6.2.1 "Colour Temperature"

## Parameter "Object datatype of colour temperature"

This parameter sets the object datatype of colour temperature. Options:

**1byte relative percentage value****2byte absolute value**

1byte relative percentage value: 0% = minimum color temperature, 100% = maximum color temperature. The value range 0-100% will automatically convert based on the colour temperature range. For example, If the colour temperature range is 1000...10000K, then a value of 50% corresponds to a color temperature of 4500K.

2byte absolute value: The colour temperature range is 1000....10000K.

## Parameter "Behaviour when switch on"

This parameter sets the colour temperature value when the group switch is on. Options:

**Via ETS parameter****Last colour temperature value**

Via ETS parameter: The colour temperature when the group object "Switch" on is set by the next

parameter.

Last colour temperature value: The colour temperature when the group object "Switch" on follows the last saved colour temperature value. If the value is uncertain, the default colour temperature is 4000K and brightness is 50%.

#### --Parameter "Colour temperature when switch on"

This parameter is visible when "Via ETS parameter" is selected, used to set the colour temperature when lamp is switch on. Options: **1000...10000K**

Parameter "Minimum colour temperature control"

Parameter "Maximum colour temperature control"

This parameter sets the minimum/maximum colour temperature control of the group output, which refers to the minimum/maximum colour temperature value controllable by the KNX-DALI-2 Gateway for lamps.

Options: **1000...10000K**

The minimum value of the output colour temperature must always be less than the maximum value; if this condition is not met, the parameters on the ETS will not be set.

Minimum colour temperature control	<input type="text" value="2700"/>	K
Maximum colour temperature control	<input type="text" value="2600"/>	K

Parameter "Dimming time via colour relative dimming"

Within the maximum colour temperature range, this parameter defines the dimming time via colour relative dimming. Options: **1...255s**

Parameter "Allow switch on via relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

Parameter "Allow switch on via set colour temperature"

This parameter defines whether to allow the lamp switch on via set colour temperature.

Parameter "Allow switch on via colour relative dimming"

This parameter defines whether to allow the lamp switch on via colour relative dimming.

## 5.6.2.2. Colour control type "RGB Colour"

Colour control type: RGB Colour

Object type for RGB Colour: ☐ RGB(Combined object) ☒ HSV(Separated objects)

Behaviour when switch on: ☒ Via ETS parameter ☐ Last colour value

Colour value when switch on: #FF0000

Correction value for special LED

Intensity of colour red: 100 %

Intensity of colour green: 100 %

Intensity of colour blue: 100 %

Dimming time via colour relative dimming: 2 s

Allow switch on via relative dimming: ☐

Allow switch on via set colour value: ☐

Allow switch on via colour relative dimming: ☒

Fig.5.6.2.2 "RGB Colour "

## Parameter "Object type for RGB Colour"

This parameter sets the object datatype of RGB Colour. Options:

**RGB(Combined object)**

**HSV(Separated objects)**

## Parameter "Behaviour when switch on"

This parameter sets the colour value when the group switch is on. Options:

**Via ETS parameter**

**Last colour value**

Via ETS parameter: The colour value when the group object "Switch" on is set by the next parameter.

Last colour temperature value: The colour value when the group object "Switch" on follows the last



saved colour value. If the value is undefined, the default colour is white with 50% brightness .

**--Parameter "Colour value when switch on"**

This parameter is visible when "Via ETS parameter" is selected, used to set the colour value when lamp is switch on. Options: **000000...FFFFFF**

Correction value for special LED

Parameter "Intensity of colour red"

Parameter "Intensity of colour green"

Parameter "Intensity of colour blue"

These parameters set the intensity of colour red/green/blue. Options: **0...100%**

**Note: If Intensity is set to 0%, the control for this colour is disabled and the colour output is 0%.**

Parameter "Dimming time via colour relative dimming"

This parameter is visible when "HSV (Separated objects)" is selected. Within the maximum intensity range of colour, it used to define the dimming time via colour relative dimming. Options: **1...255s**

Parameter "Allow switch on via relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming .

Parameter "Allow switch on via set colour value"

This parameter is visible when "HSV (Separated objects)" is selected. Used to define whether to allow the lamp switch on via set colour value.

Parameter "Allow switch on via colour relative dimming"

This parameter is visible when "HSV (Separated objects)" is selected. Used to define whether to allow the lamp switch on via colour relative dimming.

## 5.6.2.3. Colour control type "RGBW Colour"

Colour control type	RGBW Colour	
Object type for RGBW Colour	<input type="radio"/> RGBW(Combined object) <input checked="" type="radio"/> HSVW(Separated objects)	
Behaviour when switch on	<input checked="" type="radio"/> Via ETS parameter <input type="radio"/> Last colour value	
Colour value when switch on	#FF0000	
Additional White value	100	%
Correction value for special LED		
Intensity of colour red	100	%
Intensity of colour green	100	%
Intensity of colour blue	100	%
Dimming time via colour relative dimming	2	s
Allow switch on via relative dimming	<input type="checkbox"/>	
Allow switch on via set colour value	<input type="checkbox"/>	
Allow switch on via colour relative dimming	<input checked="" type="checkbox"/>	

Fig.5.6.2.3 "RGBW Colour "

## Parameter "Object type for RGBW Colour"

This parameter sets the object datatype of RGBW Colour .Options:

**RGBW(Combined object)**

**HSVW(Separated objects)**

## Parameter "Behaviour when switch on"

This parameter sets the colour value when the group switch is on.Options:

**Via ETS parameter**

**Last colour value**

Via ETS parameter: The colour value when the group object "Switch" turns on is set by the next parameter.

Last colour temperature value: The colour value when the group object "Switch" turns on follows the last saved colour value. If the value is undefined, the default colour is white and "W" value is 50% .

**The following parameters are visible when "Via ETS parameter" is selected:**

--Parameter "Colour value when switch on"

This parameter sets the colour value when switch on. Options: **000000...FFFFFF**

--Parameter "Additional White value"

This parameter sets the additional white colour value when switch on. Options: **0...100%**

Correction value for special LED

Parameter "Intensity of colour red"

Parameter "Intensity of colour green"

Parameter "Intensity of colour blue"

These parameters set the intensity of colour red/green/blue. Options: **0...100%**

**Note: If Intensity is set to 0%, the control for this colour is disabled and the colour output is 0%.**

Parameter "Dimming time via colour relative dimming"

This parameter is visible when "HSVW(Separated objects)" is selected. Within the maximum colour temperature range, used to define the dimming time via colour relative dimming. Options: **1...255s**

Parameter "Allow switch on via relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

Parameter "Allow switch on via set colour value"

This parameter is visible when "HSVW(Separated objects)" is selected. Used to define whether to allow the lamp switch on via set colour value.

Parameter "Allow switch on via colour relative dimming"

This parameter is visible when "HSVW(Separated objects)" is selected. Used to define whether to allow the lamp switch on via colour relative dimming.

## 5.6.2.4. Colour control type "XY Colour"

Fig.5.6.2.4 "XY Colour "

## Parameter "Object type for XY Colour"

This parameter sets the object datatype of XY Colour. Options:

**XY(Combined object)**

**XY(Separated objects)**

## Parameter "Behaviour when switch on"

This parameter sets the colour value when the group switch is on. Options:

**Via ETS parameter**

**Last colour value**

Via ETS parameter: The colour value when the group object "Switch" turns on is set by the next parameter.

Last colour temperature value: The colour value when the group object "Switch" turns on follows the last saved colour value. If the value is undefined, the default colour is white with 50% brightness.

**The following parameters are visible when "Via ETS parameter" is selected.**

**--Parameter "Colour X-value when switch on"**


This parameter sets the colour X-value when switch on. Options: **0...1**

**--Parameter "Colour Y-value when switch on"**

This parameter sets the colour Y-value when switch on. Options: **0...1**

**Note: All control values whose actual coordinates do not fall within the colour range are invalid,**

**such as: 0.01/0.01**



### Parameter "Allow switch on via colour relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

### 5.6.3. Parameter window "Scene"

This interface is visible when "Group scene function" is enabled.

--- KNX-DALI-2 Gateway, 2-Fold > DALI Output A > Group setting > Group 1-... > Scene

KNX Secure

General

DALI Output A

ECG/Group Template setting

Template 1-...

Group setting

Group 1-...

Colour control

**Scene**

ECG setting

ECG 1-...

+ DALI Output B

Overwrite scene stored values during download ☒

No.	Scene NO.	Brightness control	Brightness value	Colour control	Colour temp.	Colour RGB	Colour white	Colour X	Colour Y	Dimming time
No.1	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.2	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.3	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.4	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.5	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.6	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.7	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.8	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.9	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.10	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.11	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.12	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.13	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.14	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.15	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s
No.16	No assign...	<input checked="" type="checkbox"/>	0 %	<input checked="" type="checkbox"/>	NA	NA	NA	0.33	0.33	2 s

Fig.5.6.3 Parameter window "Scene"

#### Parameter "Overwrite scene stored values during download"

This parameter sets whether to overwrite scene stored values during download.

Overwrite: all parameters will be refer from the settings downloaded from ETS.

Not overwrite: The brightness and color values corresponding to scene numbers that have executed learning will still be saved after downloading, and the saved values will be used when recall the scene; for new scenes, scenes with changes in the color control type, or scene numbers for which learning has not been executed, or the location of scene numbers for which learning has been executed has been changed in the new configuration, the configuration of the ETS will take precedence.

#### Parameter "No."

This parameter shows the configurable scenarios, up to 16 scenarios.

## Parameter "Scene NO."

This parameter sets the KNX scene number that triggers this group of scenes. Options:

**No assignment**

**1**

**2**

**...**

**64**

## Parameter "Brightness control"

This parameter sets whether to enable brightness control, indicating the brightness control value that needs to be sent in this scene control.

**Note: If the ECG color type is RGB or RGBW, the gateway will automatically use the luminance value corresponding to the color value as the target brightness during execution.**

## Parameter "Brightness value"

This parameter sets the brightness value of the scene, the options are **"0...100%"**, otherwise the default is **"NA"**.

The brightness value cannot be set when the group's operation mode is "Permanent" and object type is "HSV(Separated objects)/HSVW(Separated objects)".

## Parameter "Colour control"

This parameter sets the colour value of the scene, indicating the colour control value that needs to be sent in this scene control.

**Note: When controlling group scenes, at least one of the following must be sent: brightness value or colour control.**

## Parameter "Colour temp."

This parameter sets the colour temperature value of the corresponding scene. The options are displayed according to the colour control type and can be set only if the group selection color type is **"Colour Temperature"** and the parameter **"Colour control"** is enabled. The options are **"1000...10000K"**, otherwise the default is **"NA"**.

## Parameter "Colour RGB/RGBW"

This parameter sets the RGB/RGBW value of the corresponding scene. The options are displayed according to the colour control type and can be set only if the group selection color type is **"RGB /RGBW Colour"** and the parameter **"Colour control"** is enabled. The options are **"000000...FFFFFF"**, otherwise the default is **"NA"**.

#### Parameter **"Colour White"**

This parameter sets the colour white of the corresponding scene. The options are displayed according to the colour control type and can be set only if the group selection color type is **"RGBW Colour"** and the parameter **"Colour control"** is enabled. The options are **"0...100%"**, otherwise the default is **"NA"**.

#### Parameter **"Colour X"**

This parameter sets the colour X of the corresponding scene. The options are displayed according to the colour control type and can be set only if the group selection color type is **"XY Temperature"** and the parameter **"Colour control"** is enabled. The options are **"0...1"**, otherwise the default is **"NA"**.

#### Parameter **"Colour Y"**

This parameter sets the colour Y of the corresponding scene. The options are displayed according to the colour control type and can be set only if the group selection color type is **"XY Temperature"** and the parameter **"Colour control"** is enabled. The options are **"0...1"**, otherwise the default is **"NA"**.

#### Parameter **"Dimming time"**

This parameter sets the dimming time of the corresponding scene. The options are displayed according to the the parameter **"Brightness control"** is enabled. The options are **"0...255s"**, otherwise the default is **"NA"**.



## 5.7. Parameter window“ ECG setting”



Fig.5.7 Parameter window“ECG setting”

### Parameter “Number of ECGs”

This parameter sets the number of ECGs. Options:

**None**

**1**

**2**

**...**

**64**

**Note:** This parameter should be configured according to the actual ECG used. If the parameter is configured with ECG x but the device is not connected, the ECG is considered to be faulty. Therefore, it is recommended to activate this parameter based on the ECG actually used.

In addition, the ECG configured in the group also needs to be activated via this parameter, but the control behavior applies to the configuration of the group.

### 5.7.1. Parameter window“ECG X”(X=1~64)

Parameter setting interface “ECG X” is shown in Figure5.7.1, here for setting the control of a single DALI device.

Each channel of the KNX/DALI gateway has 64 DALI devices, and each DALI device can be individually switch, dimming, brightness value, colour temperature, colour control. At the same time, the gateway also provides functions such as operation hour calculation and burn in for DALI devices.




Fig.5.7.1Parameter window“ECG X”(X=1~64)

### Parameter “Description (max. 30 char)”

This parameter is used to input the ECG name (up to 30 characters).

## Parameter "ECG type"

This parameter sets the ECG type used. Options:

**LED Module**

**ECG with Colour control**

**Relays module**

**Self-Contained Battery Lamp (non-switchable)**

LED Module: ECG type is DT6, e.g. fluorescent lamp. Set parameters in [section 5.7.1.1](#).

ECG with Colour control: ECG type is DT8, with colour control. Set parameters in [section 5.7.1.1](#), and colour setting parameters see [section 5.7.2](#).

Relays module: ECG type is DT7, relay control with switch. This type is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above. Set parameters in [section 5.7.1.1](#).

Self-Contained Battery Lamp (non-switchable): ECG type is DT1, which is without control and status communication objects for switching, brightness and etc.

**Note: Only supports connection to DALI Class D emergency lighting devices.**

**DALI defines four types of self-compensating emergency devices: A, B, C, and D. The control device can only be one of these.**

**A: The switch remains dimmable and the lamp can be dimmed or turned off when power is present; the lamp is on when power is not present.**

**B: The switch remains non-dimmable, and the lamp can be turned on or off when the power is present; the lamp is on when the power is not present.**

**C: Lamp remains on at all times regardless of the presence of power.**

**D: Non-maintainable, lamp is on only when power is not present or in test mode.**

This type is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above. Set parameters in [section 5.7.1.2](#).

### 5.7.1.1. Parameter setting "LED Module/ECG with Colour control/Relays module"

This section only describes the parameter settings only when the ECG type is LED Module/ECG with Colour control/Relays module.

Operation mode	Normal mode
ECG behaviour select	Template 1
Disable function	Disable=1/Enable=0
Behaviour on enable	Unchange
Behaviour on disable	Unchange
Panic mode	<input checked="" type="checkbox"/>
Brightness value in panic mode	50 %
Use emergency lighting with central battery	<input checked="" type="checkbox"/>
Brightness value in test mode	50 %
Duration of test mode	60 min
Operating hour calculation	<input checked="" type="checkbox"/>
Operating hour limit	4000 h
Object datatype of ECG/Lamp failure	2byte
Apply DCA setting for ECG	<input checked="" type="checkbox"/>
If enable DCA, apply the following setting in DCA:	
<div> <i>i</i> Value on DALI power fail(DALI System Failure Level)  Value on ECG power recovery(DALI Power On Level)  Minimum brightness value  Maximum brightness value  Fade time </div>	

Fig.5.7.1 Parameter setting "LED Module/ECG with Colour control/Relays module"

#### Parameter "Operating mode"

This parameter setting the operating mode of the group. Options:

**Normal mode**

**Permanent mode**

**Normal/Night mode**

### **Staircase mode**

Normal mode: Common switch control of the lamp, such as switching, dimming and setting the brightness value of the DALI device in the group.

Permanent mode: The DALI device in the group outputs with a fixed brightness value, the brightness cannot be switched or changed.

Normal/Night mode: Under the normal mode, the control is the same as the first option. After switching to night mode, the lamp can be turned off in a delay time after the lamp is turned on, or output with a fixed brightness value. Activate night mode via object 2.

Staircase mode: Turn on the Staircase lighting and automatically turn off after delay time

Parameter description of each mode refers to [section 5.6.1.1](#), [5.6.1.2](#), [5.6.1.3](#) and [5.6.1.4](#).

#### **Parameter "ECG behaviour select--Template 1"**

This parameter sets the behavior of the ECG, which is achieved by recalling the settings of the template. Options:

**Template 1**

...

**Template 8**

#### **Parameter "Disable function"**

This parameter sets the disable/enable control for the ECG.

**Disable**

**Disable=1/Enable=0**

**Disable=0/Enable=1**

**When enabled, the following parameters are visible.**

#### **--Parameter "Behaviour on enable"**

This parameter sets the behavior when the ECG is enabled. Options:

**Unchange**

**Switch on**

**Switch off**

Unchange: The ECG output is unchange.

Switch on: The ECG output executes the switch on operation.

Switch off: The ECG output executes the switch off operation.

#### --Parameter "Behaviour on disable"

This parameter sets the behavior when the ECG is disabled. Options:

**Unchange**

**Switch on**

**Switch off**

Unchange: The ECG output is unchange.

switch on: The ECG output executes the switch on operation.

switch off: The ECG output executes the switch off operation.

#### Parameter "Panic mode"

This parameter sets whether to enable the function of panic mode. When enable, panic mode can be activated via object.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### --Parameter "Brightness value in panic mode"

This parameter is visible when previous parameter is selected to enable. Used to set the brightness value in panic mode. Options:

**0%**

**1%**

**2%**

**...**

**100%**

When panic mode is activated, the lamp always maintains output at this setting brightness value and cannot be switched or changed. The group assignment will be canceled during this time, and the scene will not be recalled. When panic mode is stopped, the device will revert to its previous brightness or the setting on/off value and can be individually controlled again or reassigned to a group.

#### Parameter "Use emergency lighting with central battery"

This parameter sets whether to use emergency lighting with central battery. When enable, test mode can be activated via object, which is used to test the discharge time and capacity of the central

battery.

Any ECG types (except Self-Contained Battery Lamp) can be configured as an emergency light, even if the ECG is assigned to a group.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

**--Parameter "Brightness value in test mode"**

This parameter is visible when previous parameter is selected to enable. Used to set the brightness value in test mode. Options:

**0%**

**1%**

**2%**

**...**

**100%**

When test mode is activated, the lamp always maintains output at this setting brightness value and cannot be switched or changed. The group assignment will be canceled during this time, and the scene will not be recalled. When test mode is stopped, the configuration of groups and scenes will be reprogrammed to the ECG, and the control will take effect again.

If the gateway power failure during test mode, the untested ECG will remain standby status after power recovery, that is, the test mode will not continue until be reactivated. After the test mode is finished normally, the device will revert to its previous brightness or the setting on/off value and can be individually controlled again or reassigned to a group.

**--Parameter "Duration of test mode"**

This parameter is visible when previous parameter is selected to enable. Used to set duration of test mode. Options: **5..255 min**

**Parameter "Operating hour calculation"**

This parameter setting whether to enable operation hour calculation function.

**--Parameter "Operating hour limit"**

This parameter is visible when the previous parameter is enable and is used to set the limit value of the lamp operation hour. When the operation hour of the lamp reaches the limit value, the object "Life

time exceeded" sends an alarm to the bus. Options: **0..200000h**

**Note: The operation hour record is recorded every 5 minutes. When the bus is powered off, the recording may be incomplete because the storage time of power failure may not be sufficient. Therefore, the power failure will cause the time record to have a few minutes of error.**

#### Parameter "Object datatype of ECG/Lamp failure"

This parameter setting the object datatype of the ECG/Lamp failure. Options:

**1bit**

**1byte**

**2byte**

1bit: Does not distinguish the type of failure, whether it is a lamp failure or ECG failure, the object sends a telegram "1" to the bus.

1byte: Distinguish the failure type, bit7-ECG failure; bit6- lamp failure; bit5-bit0: ECG number 1..64.

2byte: Distinguish the failure type, bit 8 is 1 for lamp failure; bit 9 is 1 for ECG failure; bit 10 is 1 for Converter failure.

The 1 byte object value is defined as follows:

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
ECG failure	Lamp failure	ECG number1..64					

example:

1. 1000 0011 (object value 131) indicates ECG failure of ECG4;
2. 0100 0010 (object value 66) indicates lamp failure of ECG3;

This object can also be used to query the lamp and ECG failure. When the highest two bit value, both Bit7 and Bit6, of the telegram received by the object are 1, indicating to query the ECG x failure, such as:

Query the failure status of ECG3: 1100 0010 (object value 194)

If the ECG of ECG3 is faulty, the gateway will respond: 1000 0010 (object value 130)

The 2 byte object value is defined as follows:

Bit 11...Bit15	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 0-Bit 5
0	0:No error 1:Converter failure	0:No error 1:ECG failure	0:No error 1:Lamp failure	0:Response or spontaneous sending 1:Read	0:Device address 1:Group address	DALI device address :1...64 DALI group address: 0...15

**Lamp failure: One or more fixtures does not working (damaged) or are not connected.**

**ECG failure: One or more ballasts on the output of the DALI gateway do not work or are not connected.**

#### Parameter "Apply DCA setting for ECG"

This parameter sets whether apply DCA setting for ECG. When enabled, the gateway executes the operation commands is according to DCA setting, such as the value on DALI power recovery, value on DALI power failure, fade time, etc., and will not apply ETS setting. As following:

- i** Value on DALI power fail(DALI System Failure Level)
- Value on ECG power recovery(DALI Power On Level)
- Minimum brightness value
- Maximum brightness value
- Fade time

- i** Minimum physical colour temperature
- Maximum physical colour temperature
- Minimum colour temperature control
- Maximum colour temperature control



#### 5.7.1.2. Parameter setting “Self-Contained Battery Lamp (non-switchable)”

This section only describes the parameter settings only when the ECG type is Self-Contained Battery Lamp (non-switchable).

Emergency mode behaviour select	Template 1
Object datatype of ECG/Lamp failure	1bit

Fig.5.7.3 Parameter setting “Self-Contained Battery Lamp (non-switchable)”

##### Parameter “Emergency mode behaviour select”

This parameter sets the behavior of the emergency mode, which is achieved by recalling the settings of the template. Options:

**Template 1**

...

**Template 8**

When the emergency light is enabled for emergency mode or emergency function test and duration test, the behaviour will be executed according to the configuration in the selected template.

When the ECG power failure or disconnected, the light switches to emergency mode. After power recovery, it can return to normal operation mode after a delay time.

##### Parameter “Object datatype of ECG/Lamp failure”

This parameter setting the object datatype of the ECG/Lamp failure. Options:

**1bit**

**1byte**

**2byte**

The detailed explanation is the same as [section 5.7.1.1](#), and will not be repeated here.

### 5.7.2. Parameter window "Colour control"

This interface is visible when "ECG with Colour control" is selected as the ECG type.



Fig.5.7.2 "Colour control"

#### Parameter "Colour control type"

This parameter sets the colour control type for the ECG. Options:

**Colour Temperature**

**RGB Colour**

**RGBW Colour**

**XY Colour**

Colour Temperature: Cool-warm colour control.

RGB Colour: Three RGB colour controls.

RGBW Colour: Four RGBW colour controls.

XY Colour: It is a method of controlling colour in colour space through two specified coordinates.

## 5.7.2.1. Colour control type "Colour Temperature"

Colour control type	Colour Temperature
Object datatype of colour temperature	<input type="radio"/> 1byte relative percentage value <input checked="" type="radio"/> 2byte absolute value
Behaviour when switch on	<input type="radio"/> Via ETS parameter <input checked="" type="radio"/> Last colour temperature value
Colour temperature on DALI power fail (DALI System Failure Level)	3500 K
Colour temperature on ECG power recovery (DALI Power On Level)	3500 K
Minimum physical colour temperature (refer to the technical spec. of warm white)	2700 K
Maximum physical colour temperature (refer to the technical spec. of cool white)	6500 K
Minimum colour temperature control	2700 K
Maximum colour temperature control	6500 K
Dimming time via colour relative dimming	2 s
Allow switch on via relative dimming	<input type="checkbox"/>
Allow switch on via set colour temperature	<input type="checkbox"/>
Allow switch on via colour relative dimming	<input type="checkbox"/>

Fig.5.7.2.1 "Colour Temperature"

## Parameter "Object datatype of colour temperature"

This parameter sets the object datatype of colour temperature. Options:

**1byte relative percentage value**

**2byte absolute value**

## Parameter "Behaviour when switch on"

This parameter sets the colour temperature value when the ECG switch is on. Options:

**Via ETS parameter**

**Last colour temperature value**

Via ETS parameter: The colour temperature when the ECG object "Switch" on is set by the next parameter.

Last colour temperature value: The colour temperature when the ECG object "Switch" on follows the last saved colour temperature value. If the value is undefined, the default colour temperature is 4000K and brightness is 50% .

#### **--Parameter "Colour temperature when switch on"**

This parameter is visible when "Via ETS parameter" is selected, used to set the colour temperature when lamp is switch on. Options: **1000...10000K**

Parameter "Colour temperature on DALI power fail (DALI System Failure Level)"

This parameter sets the colour temperature value of the lamp after the DALI bus is powered off. This value is saved in ECG, and ECG automatically changes the output of the colour temperature value in the event of power off. Options:

<b>3000 K</b>	<b>5500 K</b>
<b>3500 K</b>	<b>6000 K</b>
<b>4000 K</b>	<b>6500 K</b>
<b>4500 K</b>	<b>Unchange</b>
<b>5000 K</b>	

Unchange: The output colour temperature value is the colour temperature value before DALI bus power off, that is, the lamp colour temperature does not change.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

Parameter "Colour temperature on ECG power recovery (DALI Power On Level)"

This parameter sets the colour temperature value of the lamp after ECG power-on reset. This value will be saved in the ECG, and the ECG will output the colour temperature value when the ECG is powered on and reset.

Options:

3000 K	5500 K
3500 K	6000 K
4000 K	6500 K
4500 K	Value before failure
5000 K	

Value before failure: The output colour temperature value is the colour temperature value before the ECG is power recovery.

**Note:** This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.

Parameter "Minimum physical colour temperature (refer to the technical spec. Of warm white)"

Parameter "Maximum physical colour temperature control (refer to the technical spec. Of warm white)"

This parameter sets the minimum/maximum physical colour temperature of the ECG output, which refers to the minimum/ maximum colour temperature value of the lamps itself, typically the colour temperature of warm/cool white LEDs.

Options: **1000...10000K**

The minimum value of the output physical colour temperature must always be less than the maximum value; if this condition is not met, the parameters on the ETS will not be set.

Minimum physical colour temperature  
(refer to the technical spec. of warm white)  K

Maximum physical colour temperature  
(refer to the technical spec. of cool white)  K

Parameter "Minimum colour temperature control"

Parameter "Maximum colour temperature control"

This parameter sets the minimum/maximum colour temperature control of the ECG output, which refers to the minimum/maximum colour temperature value controllable by the KNX-DALI-2 Gateway for lamps. Options: **1000...10000K**

The minimum value of the output colour temperature must always be less than the maximum value; if this condition is not met, the parameters on the ETS will not be set.

Minimum colour temperature control	<input type="text" value="2700"/>	K
Maximum colour temperature control	<input type="text" value="2600"/>	K

#### Parameter "Dimming time via colour relative dimming"

Within the maximum colour temperature range, this parameter defines the dimming time via colour relative dimming. Options: **1...255s**

#### Parameter "Allow switch on via relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

#### Parameter "Allow switch on via set colour temperature"

This parameter defines whether to allow the lamp switch on via set colour temperature.

#### Parameter "Allow switch on via colour relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

## 5.7.2.2. Colour control type "RGB Colour"

Colour control type	RGB Colour	
Object type for RGB Colour	<input type="radio"/> RGB(Combined object) <input checked="" type="radio"/> HSV(Separated objects)	
Behaviour when switch on	<input type="radio"/> Via ETS parameter <input checked="" type="radio"/> Last colour value	
Colour value on DALI power fail (DALI System Failure Level)	#FFFFFF	
Colour value on ECG power recovery (DALI Power On Level)	#FFFFFF	
<b>Correction value for special LED</b>		
Intensity of colour red	100	%
Intensity of colour green	100	%
Intensity of colour blue	100	%
Dimming time via colour relative dimming	2	s
Allow switch on via relative dimming	<input type="checkbox"/>	
Allow switch on via set colour value	<input type="checkbox"/>	
Allow switch on via colour relative dimming	<input type="checkbox"/>	

Fig.5.7.2.2 "RGB Colour "

## Parameter "Object type for RGB Colour"

This parameter sets the object datatype of RGB Colour.Options:

**RGB(Combined object)**

**HSV(Separated objects)**

## Parameter "Behaviour when switch on"

This parameter sets the colour value when the ECG switch is on.Options:

**Via ETS parameter**

**Last colour value**

Via ETS parameter: The colour value when the ECG object "Switch" on is set by the next parameter.

Last colour value: The colour value when the ECG object "Switch" on follows the last saved colour

value. If the value is uncertain, the default colour is white with 50% brightness .

#### --Parameter "Colour value when switch on"

This parameter is visible when "Via ETS parameter" is selected, used to set the colour value when lamp is switch on. Options: **000000...FFFFFF**

#### Parameter "Colour value on DALI power fail (DALI System Failure Level)"

This parameter sets the colour value of the lamp after the DALI bus is powered off. This value is saved in ECG, and ECG automatically changes the output of the colour value in the event of power off.

Options:

#FFFFFF White	#FFFF00 Yellow
#7F7F7F Gray	#00FFFF Cyan
#FF0000 Red	#FF00FF Purple
#00FF00 Green	Unchange
#0000FF Blue	

Unchange: The output colour value is the colour value before DALI bus power off, that is, the lamp colour value does not change.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

#### Parameter "Colour value on ECG power recovery (DALI Power On Level)"

This parameter sets the colour value of the lamp after ECG power-on reset. This value will be saved in the ECG, and the ECG will output the colour value when the ECG is powered on and reset. Options:

#FFFFFF White	#FFFF00 Yellow
#7F7F7F Gray	#00FFFF Cyan
#FF0000 Red	#FF00FF Purple
#00FF00 Green	Value before failure
#0000FF Blue	

Value before failure: The output colour value is the colour value before the ECG is power recovery.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**



Correction value for special LED

Parameter "Intensity of colour red"

Parameter "Intensity of colour green"

Parameter "Intensity of colour blue"

These parameters set the intensity of colour red/green/blue. Options: **0...100%**

**Note: If Intensity is set to 0%, the control for this colour is disabled and the colour output is 0%.**

Parameter "Dimming time via colour relative dimming"

This parameter is visible when "HSV(Separated objects)" is selected. Within the maximum intensity range of colour, it used to define the dimming time via colour relative dimming. Options: **1...255s**

Parameter "Allow switch on via relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

Parameter "Allow switch on via set colour value"

This parameter is visible when "HSV (Separated objects)" is selected. Used to define whether to allow the lamp switch on via set colour value.

Parameter "Allow switch on via colour relative dimming"

This parameter is visible when "HSV (Separated objects)" is selected. Used to define whether to allow the lamp switch on via colour relative dimming.

## 5.7.2.3. Colour control type "RGBW Colour"

Colour control type	RGBW Colour	
Object type for RGBW Colour	<input type="radio"/> RGBW(Combined object) <input checked="" type="radio"/> HSVW(Separated objects)	
Behaviour when switch on	<input type="radio"/> Via ETS parameter <input checked="" type="radio"/> Last colour value	
Colour value on DALI power fail (DALI System Failure Level)	#FFFFFF00	
Colour value on ECG power recovery (DALI Power On Level)	#FFFFFF00	
Correction value for special LED		
Intensity of colour red	100	%
Intensity of colour green	100	%
Intensity of colour blue	100	%
Dimming time via colour relative dimming	2	s
Allow switch on via relative dimming	<input type="checkbox"/>	
Allow switch on via set colour value	<input type="checkbox"/>	
Allow switch on via colour relative dimming	<input type="checkbox"/>	

Fig.5.7.2.3 "RGBW Colour "

## Parameter "Object type for RGBW Colour"

This parameter sets the object datatype of RGBW Colour .Options:

**RGBW(Combined object)**

**HSVW(Separated objects)**

## Parameter "Behaviour when switch on"

This parameter sets the colour value when the ECG switch is on.Options:

**Via ETS parameter**

**Last colour value**

Via ETS parameter: The colour value when the ECG object "Switch" turns on is set by the next parameter.

Last colour value: The colour value when the ECG object "Switch" turns on follows the last saved colour value. If the value is undefined, the default colour is white and "W" value is 50%.

**The following parameters are visible when "Via ETS parameter" is selected:**

--Parameter "Colour value when switch on"

This parameter sets the colour value when switch on. Options: **000000...FFFFFF**

--Parameter "Additional White value"

This parameter sets the additional white colour value when switch on. Options: **0...100%**

Parameter "Colour value on DALI power fail (DALI System Failure Level)"

This parameter sets the colour value of the lamp after the DALI bus is powered off. This value is saved in ECG, and ECG automatically changes the output of the colour value in the event of power off.

Options:

**#FFFFFF White**

**#FFFF00 Yellow**

**#7F7F7F Gray**

**#00FFFF Cyan**

**#FF0000 Red**

**#FF00FF Purple**

**#00FF00 Green**

**Unchange**

**#0000FF Blue**

Unchange: The output colour value is the colour value before DALI bus power off, that is, the lamp colour value does not change.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

Parameter "Colour value on ECG power recovery (DALI Power On Level)"

This parameter sets the colour value of the lamp after ECG power-on reset. This value will be saved in the ECG, and the ECG will output the colour value when the ECG is powered on and reset.

Options:

#FFFFFF White

#FFFF00 Yellow

#7F7F7F Gray

#00FFFF Cyan

#FF0000 Red

#FF00FF Purple

#00FF00 Green

Value before failure

#0000FF Blue

Value before failure: The output colour value is the colour value before the ECG is power recovery.

**Note:** This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.

#### Correction value for special LED

Parameter "Intensity of colour red"

Parameter "Intensity of colour green"

Parameter "Intensity of colour blue"

These parameters set the intensity of colour red/green/blue. Options: **0...100%**

**Note:** If Intensity is set to 0%, the control for this colour is disabled and the colour output is 0%.

Parameter "Dimming time via colour relative dimming"

This parameter is visible when "HSVW(Separated objects)" is selected. Within the maximum intensity range of colour, it used to define the dimming time via colour relative dimming. Options: **1...255s**

Parameter "Allow switch on via relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

Parameter "Allow switch on via set colour value"

This parameter is visible when "HSVW(Separated objects)" is selected. Used to define whether to allow the lamp switch on via set colour value.

Parameter "Allow switch on via set colour relative dimming"

This parameter is visible when "HSVW(Separated objects)" is selected. Used to define whether to allow the lamp switch on via colour relative dimming.

## 5.7.2.4. Colour control type "XY Colour"

Fig.5.7.2.4 "XY Colour "

## Parameter "Object type for XY Colour"

This parameter sets the object datatype of XY Colour. Options:

**XY(Combined object)**

**XY(Separated objects)**

## Parameter "Behaviour when switch on"

This parameter sets the colour value when the ECG switch is on. Options:

**Via ETS parameter**

**Last colour value**

Via ETS parameter: The colour value when the ECG object "Switch" turns on is set by the next parameter.

Last colour value: The colour value when the ECG object "Switch" turns on follows the last saved colour value. If the value is uncertain, the default colour is white with 50% brightness.

**The following parameters are visible when "Via ETS parameter" is selected.**

## --Parameter "Colour X-value when switch on"

This parameter sets the colour X-value when switch on. Options: **0...1**

## --Parameter "Colour Y-value when switch on"

This parameter sets the colour Y-value when switch on. Options: **0...1**

**Note: All control values whose actual coordinates do not fall within the colour range are invalid,**

such as: 0.01/0.01

Parameter "Colour value on DALI power fail (DALI System Failure Level)"

This parameter sets the colour value of the lamp after the DALI bus is powered off. This value is saved in ECG, and ECG automatically changes the output of the colour value in the event of power off.

Options:

<b>X=0.31,Y=0.33 White</b>	<b>X=0.42,Y=0.52 Yellow</b>
<b>X=0.31,Y=0.31 Gray</b>	<b>X=0.17,Y=0.37 Cyan</b>
<b>X=0.64,Y=0.33 Red</b>	<b>X=0.28,Y=0.14 Purple</b>
<b>X=0.30,Y=0.60 Green</b>	<b>Unchange</b>
<b>X=0.15,Y=0.06 Blue</b>	

Unchange: The output colour value is the colour value before DALI bus power off, that is, the lamp colour value does not change.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

Parameter "Colour value on ECG power recovery (DALI Power On Level)"

This parameter sets the colour value of the lamp after ECG power-on reset. This value will be saved in the ECG, and the ECG will output the colour value when the ECG is powered on and reset. Options:

<b>X=0.31,Y=0.33 White</b>	<b>X=0.42,Y=0.52 Yellow</b>
<b>X=0.31,Y=0.31 Gray</b>	<b>X=0.17,Y=0.37 Cyan</b>
<b>X=0.64,Y=0.33 Red</b>	<b>X=0.28,Y=0.14 Purple</b>
<b>X=0.30,Y=0.60 Green</b>	<b>Unchange</b>
<b>X=0.15,Y=0.06 Blue</b>	

Value before failure: The output colour value is the colour value before the ECG is power recovery.

**Note: This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.**

Parameter "Dimming time via set colour value"

This parameter defines the dimming time of the XY colour value. That is, the dimming time of the XY value from 0 to 1. Options: **0...255s**

Parameter "Allow switch on via colour relative dimming"

This parameter defines whether to allow the lamp switch on via relative dimming.

## 5.8. Parameter window "Motion sensor setting"

**Note:** This function is only suitable for versions with database versions of 2.0 or above, and DCA versions of 2.0.0.1 or above.




Fig.5.8 Parameter window "Motion sensor setting"

Parameter "Number of movement detectors"

This parameter sets the number of movement detectors, up to 8 movement detectors for per output channel. Additionally, each movement detector can link to a brightness sensor. Options:

**None**

**1**

**2**

**...**

**8**

**i** The DALI Gateway only supports DALI motion sensors with brightness sensor according DALI IEC 63286 Part 303/304

## 5.8.1. Parameter window "Motion sensor X" (X=1~8)

Description (max. 30 char)	<input type="text"/>
<b>DALI configuration</b>	
Hold time	5min
Dead time between movement detections	0.1s
<b>KNX configuration</b>	
Type of output	<input checked="" type="radio"/> 1bit <input type="radio"/> 1byte
Behaviour on begin of movement	<input type="radio"/> No action <input checked="" type="radio"/> Send a value
Value	<input type="radio"/> OFF <input checked="" type="radio"/> ON
Behaviour on end of movement	<input type="radio"/> No action <input checked="" type="radio"/> Send a value
Value	<input checked="" type="radio"/> OFF <input type="radio"/> ON
Send telegram when the result change	<input checked="" type="checkbox"/>
Cyclically send telegram [0...255,0=inactive]	10 min
Disable movement function	Disable
Additional brightness sensor	<input checked="" type="checkbox"/>
Detector depending on brightness	<input checked="" type="checkbox"/>
Brightness threshold for presence evaluation [1..2000]	300 lux

Fig.5.8.1 Parameter window "Motion sensor X"

## Parameter "Description (max.30 char)"

This parameter is used to input the sensor name (up to 30 characters).

## DALI configuration

## Parameter "Hold time"

This parameter sets hold time. After this time, the presence status will be unoccupied, that is if no movement is detected in this setting time, it can be assumed that no one is within the range of the movement detector.



Options:

**1s**  
**1min**  
**...**  
**35min**  
**40min**

**Parameter “Dead time between movement detections”**

This parameter sets dead time between movement detections, that is, the detector will respond after this setting time since the end of last movement. Options:

**None**  
**0.1s**  
**0.2s**  
**0.5s**  
**1s**  
**2s**

**KNX configuration**

**Parameter “Type of output”**

This parameter sets the type of output. Options:

**1bit**  
**1byte**

**Parameter “Object datatype”**

This parameter sets the 1byte object datatype of output. Options:

**1byte percentage value**  
**1byte unsigned value**  
**Scene number**

**Parameter “Behaviour on begin of movement”**

**Parameter “Behaviour on end of movement”**

These two parameter set whether send a value when behaviour on begin or end of movement.

Options:

**No action**

**Send a value**

**Parameter “Value”**

This parameter sets the output value when behaviour on begin or end of movement. Options are displayed according to the object datatype.

When 1bit, options:

**OFF**

**ON**

When 1byte percentage value, options:

**0%**

**1%**

**...**

**100%**

When 1byte unsigned value, options: **0..255**

When scene number, options:

**Scene NO.1**

**Scene NO.2**

**...**

**Scene NO.64**

**Parameter “Send telegram when the result change”**

This parameter sets whether send a telegram when the result of movement detection change.

**Parameter “Cyclically send telegram [0...255,0=inactive]”**

This parameter sets the time for cyclically sending the result of movement detection to the bus.

Options: **0..255 min**

**Parameter “Disable movement function”**

This parameter sets whether enable the disable movement function.

Options:

**Disable**

**Disable=1/Enable=0**

**Disable=0/Enable=1**

Parameter "Additional brightness sensor"

This parameter sets whether enable additional brightness sensor.

Parameter "Detector depending on brightness"

This parameter is visible when previous parameter is selected to enable. Used to set whether the presence control depending on brightness. When enabled, a following parameter is visible.

Parameter "Brightness threshold for presence evaluation [1..2000]"

This parameter is visible when previous parameter is selected to enable. Used to set the brightness threshold for evaluating begin of presence. Options: **1..2000 lux**

Only when brightness lower than this threshold, and there is a presence, detector will execute begin of presence.

**Note:**

**1.The end of movement telegram Does not take the brightness threshold into account.**

**2.Some DALI sensors do not update motion status in real time. The gateway reacts based on the cached current motion status and the updated brightness value from the sensor to determine whether to send Begin of movement telegram.**

### 5.8.2. Parameter window "Brightness sensor"

This parameter window is visible when additional brightness sensor is selected to enable.

The screenshot shows a configuration window for a brightness sensor. It is divided into two main sections: 'DALI configuration' and 'KNX configuration'.

**DALI configuration:**

- Dead time between brightness events:** A dropdown menu currently set to '2s'.
- Hysteresis value:** A numeric input field set to '10' with a '%' symbol next to it.
- Send brightness when the result change by:** A dropdown menu set to '10' with a 'lux' unit next to it.

**KNX configuration:**

- Brightness calibration:** A numeric input field set to '0' with a 'lux' unit next to it.
- Threshold value for brightness alarm:** A numeric input field set to '500' with a 'lux' unit next to it.
- Hysteresis value for brightness alarm:** A dropdown menu set to '10'.
- If value < threshold, send:** Two radio buttons, 'OFF' (selected) and 'ON'.
- Cyclically send brightness [0...255,0=inactive]:** A numeric input field set to '10' with a 'min' unit next to it.

Fig.5.8.2 Parameter window "Brightness sensor"

#### DALI configuration

##### Parameter "Dead time between brightness events"

This parameter sets dead time between brightness events, that is, the sensor will respond after this setting time since the end of last brightness detection. Options:

**None**

**1s**

**2s**

**...**

**10s**

##### Parameter "Hysteresis value"

This parameter sets hysteresis value of brightness sensor. Options: **0...25 %**

##### Parameter "Send brightness when the result change by"

This parameter sets when brightness turns to a certain value send the current brightness value to the bus.

Options:

**1 lux**

**2 lux**

**....**

**225 lux**

**250 lux**

#### **KNX configuration**

##### **Parameter "Brightness calibration"**

This parameter sets the brightness calibration value. Options: **-500...500 lux**

##### **Parameter "Threshold value for brightness alarm"**

This parameter sets the threshold value for brightness alarm. Options: **5...2000 lux**

##### **Parameter "Hysteresis value for brightness alarm"**

This parameter sets the hysteresis value for brightness alarm. Options:

**1 lux**

**2 lux**

**....**

**225 lux**

**250 lux**

##### **Parameter "If value < threshold, send"**

This parameter sets the out value when brightness value is lower than the value(Threshold value for brightness alarm- Hysteresis value for brightness alarm). Options:

**OFF**

**ON**

##### **Parameter "Cyclically send brightness [0...255,0=inactive]"**

This parameter sets the time for cyclically sending the the brightness detection value to the bus to the bus. Options: **0..255 min**

## Chapter 6 Description of Communication Object

The communication object is the medium through which the device communicates with other devices on the bus, that is, only the communication object can execute bus communication. The role of each communication object is described in detail below.

**Note:** In the following column of the table attribute, "C" means to enable the communication function of the communication object, "W" means that the communication object value can be rewritten by the bus, "R" means that the communication object value can be read by the bus, "T" means that the communication object has a transmission function, "U" means that the communication object value can be updated.

In DALI control, a group address cannot connect too many communication objects, because the DALI protocol baud rate is only 1.2k, relatively low, allowing up to 7 communication objects to be connected to a group address, otherwise the control may be abnormal, such as it takes a few seconds for the control to complete.

### 6.1. General Communication Object

	Number ^	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	Data Type	Priority
	1	General	In operation			1 bit	C	R	-	T	-	switch	Low

Fig.6.1 “General” Communication object

NO.	Name	Object function	Types	Attributes	DPT
1	<b>General</b>	<b>In operation</b>	<b>1bit</b>	<b>C,R,T</b>	<b>1.001 switch</b>
This communication object is used to periodically send a telegram "1" to the bus to indicate that the device is functioning properly. This communication object is always enabled.					

Table 6.1 “General” Communication object

## 6.2. Channel General Communication Object

Numb	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	I	Data Type	Priority
2	Output A General	Normal(day)/Night mode			1 bit	C	-	W	-	-	-	day/night	Low
3	Output A General	Burn In function			1 bit	C	-	W	-	-	-	start/stop	Low
4	Output A General	DALI short circuit			1 bit	C	R	-	T	-	-	alarm	Low
5	Output A General	DALI power supply			1 bit	C	R	-	T	-	-	alarm	Low
6	Output A General	General failure			1 bit	C	R	-	T	-	-	alarm	Low
7	Output A General	Lamp/ECG Failure status			1 byte	C	-	W	T	-	-	diagnostic value	Low
8	Output A General	General failure exceeds threshold			1 bit	C	R	-	T	-	-	alarm	Low
9	Output A General	General failure in Total			1 byte	C	R	-	T	-	-	counter pulses (0..255)	Low
10	Output A General	Lamp failure exceeds threshold			1 bit	C	R	-	T	-	-	alarm	Low
11	Output A General	Lamp failure in Total			1 byte	C	R	-	T	-	-	counter pulses (0..255)	Low
12	Output A General	ECG failure exceeds threshold			1 bit	C	R	-	T	-	-	alarm	Low
13	Output A General	ECG failure in Total			1 byte	C	R	-	T	-	-	counter pulses (0..255)	Low
14	Output A General	Read DALI bus voltage(V)			4 bytes	C	R	-	-	-	-	electric potential (V)	Low
15	Output A General	Read DALI bus current(mA)			2 bytes	C	R	-	-	-	-	current (mA)	Low
16	Output A General	Global scene recall/store via KNX scene			1 byte	C	-	W	-	-	-	scene control	Low
17	Output A General	Converter failure in Total			1 byte	C	R	-	T	-	-	counter pulses (0..255)	Low
18	Output A General	Converter failure exceeds threshold			1 bit	C	R	-	T	-	-	alarm	Low
19	Output A General	Test mode			1 bit	C	-	W	-	-	-	start/stop	Low
20	Output A General	Converter inhibit mode			1 bit	C	-	W	-	-	-	state	Low
21	Output A General	Panic mode			1 bit	C	-	W	-	-	-	start/stop	Low
22	Output A Broadcast	Switch			1 bit	C	-	W	-	-	-	switch	Low
23	Output A Broadcast	Brightness dimming			1 byte	C	-	W	-	-	-	percentage (0..100%)	Low
24	Output A Broadcast	Absolute colour temperature			2 bytes	C	-	W	-	-	-	absolute colour temperat...	Low
24	Output A Broadcast	HSV Hue(H) value			1 byte	C	-	W	-	-	-	angle (degrees)	Low
25	Output A Broadcast	HSV Saturation(S) value			1 byte	C	-	W	-	-	-	percentage (0..100%)	Low
26	Output A Broadcast	White colour value			1 byte	C	-	W	-	-	-	percentage (0..100%)	Low
24	Output A Broadcast	Colour XY value			6 bytes	C	-	W	-	-	-	colour xyY	Low
1851	Output A General	ECGs scene recall/store via DALI scene			1 byte	C	-	W	-	-	-	scene control	Low

Fig.6.2 “X: General” Communication object

NO.	Name	Object function	Types	Attributes	DPT
2	<b>Output X - General</b>	<b>Normal(day)/Night mode</b>	<b>1bit</b>	<b>C,W</b>	<b>1.024 day/night</b>
<p>This communication object is used to enable or disable night mode via the bus. The object value is defined by the parameter "Normal (day)/Night mode".</p>					
3	<b>Output X - General</b>	<b>Burn In function</b>	<b>1bit</b>	<b>C,W</b>	<b>1.010 start/stop</b>
<p>This communication object is used to enable or disable automatic burn in of the group. During the burn in process, all other switch, dimming or brightness value setting telegrams are ignored and the lamp is all on.</p> <p>Burn in is usually done automatically after the configured burn in time. If the burn in is stopped by this object, the burn in will also stop timing, and the burn in will need to be restarted by this object, and the timing will start again.</p>					

4	Output X - General	DALI short circuit	1bit	C,R,T	1.005 alarm																
<p>This communication object is used to report whether there is a short circuit in the connected DALI bus. Telegram:</p> <p>1—A short circuit or over-current condition occurs at the DALI communication terminal</p> <p>0—DALI communication terminal returns to normal</p>																					
5	Output X - General	DALI power supply	1byte	C,R,T	1.005 alarm																
<p>The communication object is visible when "Failure object DALI power supply" is enable.Used to report abnormality of DALI power supply. Telegram:</p> <p>1—Failure</p> <p>0—Normal</p>																					
6	Output X - General	General failure	1bit	C,R,T	1.005 alarm																
<p>This communication object is used to report failures on the DALI bus. When any type of failure occurs, the object will send a telegram "1" to the bus, and the failure will be cleared to "0".</p>																					
7	Output X - General	Lamp/ECG Failure status	1byte	C,W,T	238.600 DALI Diagnostics																
<p>The communication object is visible when "Central failure object "Lamp/ECG Failure status" is enable. Used to send the lamp or ECG failure status.</p> <p>The bits of the 1byte object are defined as follows:</p> <table><tr><td>Bit 7</td><td>Bit 6</td><td>Bit 5</td><td>Bit 4</td><td>Bit 3</td><td>Bit 2</td><td>Bit 1</td><td>Bit 0</td></tr><tr><td>ECG failure</td><td>Lamp failure</td><td colspan="6">ECG Number 1..64(value 0..63)</td></tr></table> <p><b>Example:</b></p> <p>1. 1000 0011 (object value 131) represents the ECG failure of ECG4;</p> <p>2. 0100 0010 (object value 66) represents the ECG failure of ECG3;</p> <p>This object can also be used to query the lamp and ECG failure. When the highest two bit value, both Bit7 and Bit6, of the telegram received by the object are 1, indicating to query the ECG x failure, such as:</p> <p><b>Query the failure status of ECG3: 1100 0010 (object value 194)</b></p> <p><b>If the ECG of ECG3 is faulty, the gateway will respond: 1000 0010 (object value 130)</b></p>						Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	ECG failure	Lamp failure	ECG Number 1..64(value 0..63)					
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0														
ECG failure	Lamp failure	ECG Number 1..64(value 0..63)																			



8	Output X - General	General failure exceeds threshold	1bit	C,R,T	1.005 alarm
<p>This communication object is used to report that the total number of all lamps and ECG failures exceeds the set threshold.</p>					
9	Output X - General	General failure in Total	1byte	C,R,T	5.010 counter pulses
<p>This communication object is used to report the total number of all lamps and ECG failures.</p> <p><b>Note: When the ECG fails, the lamp will be faulty at the same time. It will only be counted once. Because the ECG is faulty, the lamp failure cannot be recognized or counted.</b></p>					
9	Output X - General	General failure in %	1byte	C,R,T	5.001 percentage(0..100%)
<p>This communication object is used to report the failure rate, which is the percentage of the total number of devices on the DALI bus. All lamps and ECGs are taken into account.</p> <p><b>Note: When the ECG fails, the lamp will be faulty at the same time. It will only be counted once. Because the ECG is faulty, the lamp failure is not recognized or counted.</b></p>					
10	Output X - General	Lamp failure exceeds threshold	1bit	C,R,T	1.005 alarm
<p>This communication object is used to report that the total number of all lamp failures identified by the gateway exceeds the set threshold.</p>					
11	Output X - General	Lamp failure in Total	1byte	C,R,T	5.010 counter pulses
<p>This communication object is used to report the total number of all lamp failures identified by the gateway.</p>					
11	Output X - General	Lamp failure in %	1byte	C,R,T	5.001 percentage(0..100%)
<p>This communication object is used to report the failure rate, which is the percentage of faulty lamps in all lamps on the DALI bus.</p>					
12	Output X - General	ECG failure exceeds threshold	1bit	C,R,T	1.005 alarm
<p>This communication object is used to report that the total number of all ECG failures identified by the gateway exceeds the set threshold.</p>					

<b>13</b>	<b>Output X - General</b>	<b>ECG failure in Total</b>	<b>1byte</b>	<b>C,R,T</b>	<b>5.010 counter pulses</b>
This communication object is used to report the total number of all ECG failures identified by the gateway.					
<b>13</b>	<b>Output X - General</b>	<b>ECG failure in %</b>	<b>1byte</b>	<b>C,R,T</b>	<b>5.001 percentage(0..100%)</b>
This communication object is used to report the failure rate, i.e the percentage of the faulty ECG to the total number of ECGs on the DALI bus.					
<b>14</b>	<b>Output X - General</b>	<b>Read DALI bus voltage(V)</b>	<b>4byte</b>	<b>C,R</b>	<b>14.027 electric potential(V)</b>
The communication object is visible when "Read DALI bus voltage" is enable. Used to read the DALI bus voltage.					
<b>15</b>	<b>Output X - General</b>	<b>Read DALI bus current(mA)</b>	<b>2byte</b>	<b>C,R</b>	<b>7.012 current(mA)</b>
The communication object is visible when "Read DALI bus current" is enable. Used to read the DALI bus current.					
<b>16</b>	<b>Output X - General</b>	<b>Global scene recall/store via KNX scene</b>	<b>1byte</b>	<b>C,W</b>	<b>18.001 scene control</b>
<p>This communication object is used to recall or store a global scene. Up to 16 scenes are available for the DALI gateway.</p> <p>The KNX scene number assignment, and allow to add ECGs or groups to the scene and set the target brightness, colour temperature and colour for each ECGs or groups. There are 64 scene numbers available. The KNX scene number is defined as follows:</p> <p>Set an 8bit instruction as (binary code): FXNNNNNN</p> <p>F: call the scene for '0'; store the scene for '1';</p> <p>X:0;</p> <p>NNNNNN: Scene number (0...63).</p> <p>The options are KNX Scene No.1~64. In fact, the scene telegram received by the communication object corresponds to 0~63. As follows:</p>					

Scene number	Call the message value of the scene object	Store the message value of the scene object
KNX Scene No.1	0	128
KNX Scene No.2	1	129
KNX Scene No.3	2	130
...	...	...
KNX Scene No.64	63	191

Such as setting KNX Scene No.1, the scene telegram received by the communication object should be 0.

<b>17</b>	<b>Output X General</b>	<b>Converter failure in Total</b>	<b>1byte</b>	<b>C,R,T</b>	<b>5.010 counter pulses</b>
-----------	-------------------------	-----------------------------------	--------------	--------------	-----------------------------

This communication object is used to report the total number of all converter failures identified by the gateway.

<b>17</b>	<b>Output X General</b>	<b>Converter failure in %</b>	<b>1bit</b>	<b>C,R,T</b>	<b>5.001 percentage(0..100%)</b>
-----------	-------------------------	-------------------------------	-------------	--------------	--------------------------------------

This communication object is used to report the failure rate, which is the percentage of faulty lamps in all converters of the DALI bus.

<b>18</b>	<b>Output X General</b>	<b>Converter failure exceeds threshold</b>	<b>1bit</b>	<b>C,W</b>	<b>1.005 alarm</b>
-----------	-------------------------	--	-------------	------------	--------------------

This communication object is used to report that the total number of all converter failures identified by the gateway exceeds the set threshold.

<b>19</b>	<b>Output X General</b>	<b>Test mode</b>	<b>1bit</b>	<b>C,W</b>	<b>1.010 start/stop</b>
-----------	-------------------------	------------------	-------------	------------	-------------------------

This communication object is used to activate/stop test mode for central battery emergency lights.

Telegrams:

1—Active

0—Stop

After the setting duration time, the test can also be automatically stopped (set independently in the each ECG).

20	Output X General	Converter inhibit mode	1bit	C,W	1.011 state
<p>This communication object is used to active/inactive inhibit mode for self-contained battery lamps.</p> <p>Telegrams:</p> <p>1—Active</p> <p>0—Inactive</p> <p>When active, emergency light will not change to emergency mode when power supply failure.</p> <p>When inactive, emergency light is in normal mode, and will change to emergency mode when power supply failure.</p>					
21	Output X General	Panic mode	1bit	C,W	1.010 start/stop
<p>This communication object is used to activate/stop panic mode for all ECGs and lamps. Telegrams:</p> <p>1—Active</p> <p>0—Stop</p>					
22	Output X - Broadcast	Switch	1bit	C,W	1.001 switch
<p>The communication object is visible when “Broadcast control function” is enable. Used for broadcast control and can turn all connected lamps on the channel on or off. All ECGs can be switched at the same time, and the brightness value of the on is 100%, and the brightness value of the off is 0%.</p> <p>Telegram:</p> <p>1—ON</p> <p>0—OFF</p> <p><b>If the ECG works in the permanent mode, after the broadcast control is turned on, if the ECG brightness read by the gateway from the DALI bus does not match the brightness of the permanent mode, the brightness will become the brightness of the normal mode again.</b></p>					
23	Output X - Broadcast	Brightness dimming	1byte	C,W	5.001 percentage(0..100%)
<p>This communication object is used for broadcast control to set a specific brightness value for all connected lamps on the channel. Telegram: 0...100%</p>					

24	Output X - Broadcast	Absolute colour temperature	2byte	C,W	7.600 absolute colour temperature
This communication object is visible when "Colour Temperature" is selected for the colour control type. Used for broadcasting colour control.					
24	Output X - Broadcast	RGB colour value RGBW colour value HSV Hue(H) value	3byte 6byte 1byte	C,W	232.600 RGB value 3x (0..255) 251.600 RGBW value4x (0...100%) 5.003 angle(degrees)
24	Output X - Broadcast	Colour XY value Colour X value	6byte 2byte	C,W	242.600 Colour xyY 7.001 pulses
25	Output X - Broadcast	Colour Y value	2byte	C,W	7.001 pulses
25	Output X - Broadcast	HSV Saturation(S) value	1byte	C,W	5.001 percentage
26	Output X - Broadcast	White colour value	1byte	C,W	5.001 percentage
<p>Displays objects according to the colour control type. Used for broadcasting colour control.</p> <p>RGB colour value: Setting the RGB value</p> <p>RGBW colour value: Setting the RGBW value</p> <p>White colour value: Setting the White colour value</p> <p>HSV Hue(H) value: Setting the HSV Hue(H) value</p> <p>HSV Saturation(S) value: Setting the HSV Saturation(S) value</p> <p>Colour XY value: Setting the XY value</p> <p>Colour X value:Setting the X value</p> <p>Colour Y value:Setting the Y value</p>					
1851	Output X - General	ECGs scene recall/store via DALI scene	1byte	C,W	18.001 scene control
This communication object is used to recall/store DALI scene via KNX bus, up to 16 scenes are available for ECGs .					

The scene number assignment are configured in the DCA, there are 16 scene numbers available.

Telegram is defined as follows:

Set an 8bit instruction as (binary code): FXNNNNNN

F: call the scene for '0'; store the scene for '1';

X:0;

NNNNNN: Scene number (0...15).

The options are Scene 1st~16th. In fact, the scene telegram received by the communication object corresponds to 0~15. As follows:

Scene number	Call the message value of the scene object	Store the message value of the scene object
Scene 1st	0	128
Scene 2nd	1	129
Scene 3rd	2	130
...	...	...
Scene 16th	15	143

Such as setting Scene 1st, the scene telegram received by the communication object should be 0.

Table 6.2 “X: General” Communication object

### 6.3. Channel Communication Object of a Single Group

There are 16 groups in the channel. The communication objects of each group are the same and independent of each other. Let's take one of them as an example:

Numb	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	I	Data Type	Priority
27	Output A Group 1-...	Disable function			1 bit	C	-	W	-	-	-	enable	Low
28	Output A Group 1-...	Switch			1 bit	C	-	W	-	-	-	switch	Low
29	Output A Group 1-...	Relative dimming			4 bit	C	-	W	-	-	-	dimming control	Low
30	Output A Group 1-...	Brightness dimming			1 byte	C	-	W	-	-	-	percentage (0..100%)	Low
31	Output A Group 1-...	Switch status			1 bit	C	R	-	T	-	-	switch	Low
32	Output A Group 1-...	Brightness status			1 byte	C	R	-	T	-	-	percentage (0..100%)	Low
33	Output A Group 1-...	Absolute colour temperature			2 bytes	C	-	W	-	-	-	absolute colour temperat...	Low
36	Output A Group 1-...	Relative colour Temperature			4 bit	C	-	W	-	-	-	dimming control	Low
40	Output A Group 1-...	Absolute colour temperature, status			2 bytes	C	R	-	T	-	-	absolute colour temperat...	Low
43	Output A Group 1-...	Group scene recall/store via KNX scene			1 byte	C	-	W	-	-	-	scene control	Low

#### Colour Temperature

33	Output A Group 1-...	RGB colour value			3 bytes	C	-	W	-	-	-	RGB value 3x(0..255)	Low
40	Output A Group 1-...	RGB colour value, status			3 bytes	C	R	-	T	-	-	RGB value 3x(0..255)	Low

#### RGB(Combined object)

33	Output A Group 1-...	HSV Hue(H) value			1 byte	C	-	W	-	-	-	angle (degrees)	Low
34	Output A Group 1-...	HSV Saturation(S) value			1 byte	C	-	W	-	-	-	percentage (0..100%)	Low
40	Output A Group 1-...	HSV Hue(H) value, status			1 byte	C	R	-	T	-	-	angle (degrees)	Low
41	Output A Group 1-...	HSV Saturation(S) value, status			1 byte	C	R	-	T	-	-	percentage (0..100%)	Low

#### RGB(Separated objects)

33	Output A Group 1-...	RGBW colour value			6 bytes	C	-	W	-	-	-	RGBW value 4x(0..100%)	Low
40	Output A Group 1-...	RGBW colour value, status			6 bytes	C	R	-	T	-	-	RGBW value 4x(0..100%)	Low

#### RGBW(Combined object)

36	Output A Group 1-...	Relative HSV Hue(H) value			4 bit	C	-	W	-	-	-	dimming control	Low
37	Output A Group 1-...	Relative HSV Saturation(S) value			4 bit	C	-	W	-	-	-	dimming control	Low
40	Output A Group 1-...	HSV Hue(H) value, status			1 byte	C	R	-	T	-	-	angle (degrees)	Low
41	Output A Group 1-...	HSV Saturation(S) value, status			1 byte	C	R	-	T	-	-	percentage (0..100%)	Low
42	Output A Group 1-...	White colour value, status			1 byte	C	R	-	T	-	-	percentage (0..100%)	Low

#### RGBW(Separated objects)

33	Output A Group 1-...	Colour XY value			6 bytes	C	-	W	-	-	-	colour xyY	
40	Output A Group 1-...	Colour XY value, status			6 bytes	C	R	-	T	-	-	colour xyY	

#### XY(Combined object)

33	Output A Group 1-...	Colour X value			2 bytes	C	-	W	-	-	-	pulses	Low
34	Output A Group 1-...	Colour Y value			2 bytes	C	-	W	-	-	-	pulses	Low
40	Output A Group 1-...	Colour X value, status			2 bytes	C	R	-	T	-	-	pulses	Low
41	Output A Group 1-...	Colour Y value, status			2 bytes	C	R	-	T	-	-	pulses	Low

#### XY(Separated objects)

Fig.6.3 “X: Group” Communication object

NO.	Name	Object function	Types	Attributes	DPT																																				
27	Output X Group y-{{...}}	Disable function	1bit	C,W	1.003 enable																																				
<p>The communication object is visible when “Disable function” is enable. Used to disable/enable control of ECGs in group, the trigger value is defined by the parameter, the device reboot is enabled by default.</p> <p>The name in parentheses changes with the parameter “Description (max 30char.)”. If description is empty, display “Output X Group y-...” by default. The same below.</p>																																									
28	Output X Group y-{{...}}	Switch	1bit	C,W	1.001 DPT_Switch																																				
<p>This communication object is used to switch on or off the ECGs in group, y=1..16.</p> <p>The value for "Switch on" can be defined by a parameter template. See <a href="#">section 5.4.1</a> for details.</p>																																									
29	Output X Group y-{{...}}	Relative dimming	4bit	C,W	3.007 dimming control																																				
<p>This communication object is used for relative dimming of the ECGs in group. The highest bit Bit4 decides to brighten or darken, Bit 0..3 determines the dimming size, and Bit 0..3 is 0 to stop dimming. The correspondence between the value of the relatively dimming telegram and brightness chance is as follows:</p> <table><tr><td>Telegram value</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td></tr><tr><td>Decrease the brightness value</td><td>stop</td><td>(100%)</td><td>(50%)</td><td>(25%)</td><td>(12%)</td><td>(6%)</td><td>(3%)</td><td>(1%)</td></tr><tr><td>Telegram value</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td></tr><tr><td>Increase the brightness value</td><td>stop</td><td>(100%)</td><td>(50%)</td><td>(25%)</td><td>(12%)</td><td>(6%)</td><td>(3%)</td><td>(1%)</td></tr></table> <p><b>Note: In the DALI system,stop dimming is unsupported. When the gateway receives the command of stop dimming, it will send the current brightness status to the DALI bus again.</b></p>						Telegram value	0	1	2	3	4	5	6	7	Decrease the brightness value	stop	(100%)	(50%)	(25%)	(12%)	(6%)	(3%)	(1%)	Telegram value	8	9	10	11	12	13	14	15	Increase the brightness value	stop	(100%)	(50%)	(25%)	(12%)	(6%)	(3%)	(1%)
Telegram value	0	1	2	3	4	5	6	7																																	
Decrease the brightness value	stop	(100%)	(50%)	(25%)	(12%)	(6%)	(3%)	(1%)																																	
Telegram value	8	9	10	11	12	13	14	15																																	
Increase the brightness value	stop	(100%)	(50%)	(25%)	(12%)	(6%)	(3%)	(1%)																																	
30	Output X Group y-{{...}}	Brightness dimming	1byte	C,W	5.001 percentage(0..100%)																																				
<p>This communication object is used to set the brightness value of the ECGs in group.</p>																																									



31	Output X Group y-{{...}}	Switch status	1bit	C,R,T	1.001 Switch
<p>This communication object is used to send the switch status of the ECGs in group.</p> <p><b>Note: The correct feedback of the status is guaranteed only in the case of group control.</b></p>					
32	Output X Group y-{{...}}	Brightness status	1byte	C,R,T	5.001 percentage(0..100%)
<p>This communication object is used to send the brightness status of the ECGs in group.</p> <p><b>Note: The correct feedback of the status is guaranteed only in the case of group control.</b></p>					
33	Output X Group y-{{...}}	Absolute colour temperature	2byte	C,W	7.600 absolute colour temperature(K)
<p>This communication object is used to set the absolute colour temperature of the ECGs in group. Range is setting by parameters.</p>					
33	Output X Group y-{{...}}	Relative percentage colour temperature	1byte	C,W	5.001 percentage(0..100%)
<p>This communication object is used to control the relative colour temperature via a percentage object type.</p>					
33	Output X Group y-{{...}}	RGB colour value RGBW colour value HSV Hue(H) value Colour XY value Colour X value	3byte 6byte 1byte 6byte 2byte	C,W	232.600 RGB value 3x(0..255) 251.600 RGBW value 4x(0..100%) 5.003 angle(degrees) 242.600 Colour xyY 7.001 pulses
34	Output X Group y-{{...}}	HSV Saturation(S) value Colour Y value	1byte 2byte	C,W	5.001 percentage(0..100%) 7.001 pulses
35	Output X Group y-{{...}}	White colour value	1byte	C,W	5.001 percentage(0..100%)

Displays objects according to the colour control type. Used for colour control of ECGs in group.

RGB colour value: Setting the RGB value

RGBW colour value: Setting the RGBW value

HSV Hue(H) value: Setting the HSV Hue(H) value

HSV Saturation(S) value: Setting the HSV Saturation(S) value

White colour value: Setting the White colour value

Colour XY value: Setting the XY value

Colour X value:Setting the X value

Colour Y value:Setting the Y value

<b>36</b>	<b>Output X Group y-{{...}}</b>	<b>Relative colour Temperature</b>	<b>4bit</b>	<b>C,W</b>	<b>3.007 dimming control</b>
-----------	---------------------------------	--	-------------	------------	------------------------------

The communication object adjusts the colour temperature of the ECGs in group by relative dimming. The telegram value refers to object 29.

The new color temperature value is calculated relative to the current color temperature value, for example, If the maximum value of colour temperature is set to 6500K, the minimum value is 2700K, and the current colour temperature value is 3000K, adjusted increase by 50%, the new colour temperature value is 4900K, as follows:

Telegram value	0	1	2	3	4	5	6	7
Decrease the colour temperature value	stop	(100%)	(50%)	(25%)	(12%)	(6%)	(3%)	(1%)
Telegram value	8	9	10	11	12	13	14	15
Increase the colour temperature value	stop	(100%)	(50%)	(25%)	(12%)	(6%)	(3%)	(1%)

**Note: In the DALI system,stop Relative Control is supported.**

36	Output X Group y-{{...}}	Relative HSV Hue(H) value	4bit	C,W	3.007 dimming control
37	Output X Group y-{{...}}	Relative HSV Saturation(S) value	4bit	C,W	3.007 dimming control
38	Output X Group y-{{...}}	Relative white colour value	4bit	C,W	3.007 dimming control
Displaying objects according to colour control type. Used for relative adjustment of colour.					
40	Output X Group y-{{...}}	Absolute colour temperature, status	2byte	C,R,T	7.600 absolute colour temperature
This communication object is used to send the current absolute colour temperature value of the ECGs in group to the bus.					
40	Output X Group y-{{...}}	Relative percentage colour temperature, status	1byte	C,R,T	5.001 percentage(0..100%)
This communication object sends the relative colour temperature status as a percentage to the bus.					
40	Output X Group y-{{...}}	RGB colour value, status RGBW colour value, status HSV Hue(H) value, status Colour XY value, status Colour X value, status	3byte 6byte 1byte 6byte 2byte	C,R,T	232.600 RGB value 3x(0..255) 251.600 RGBW value 4x(0...100%) 5.003 angle(degrees) 242.600 Colour xyY 7.001 pulses
41	Output X Group y-{{...}}	HSV Saturation(S) value, status Colour Y value, status	1byte 2byte	C,R,T	5.001 percentage(0..100%) 7.001 pulses
42	Output X Group y-{{...}}	HSV Saturation(S) value, status	1byte	C,R,T	5.001 percentage(0..100%)

42	Output X Group y-{{...}}	White colour value, status	1byte	C,R,T	5.001 percentage(0..100%)																		
Displaying objects according to colour control type. Used to send status in various colour																							
43	Output X Group y-{{...}}	Group scene recall /store via KNX scene	1byte	C,W	18.001 scene control																		
<p>The communication object is visible when “Group scene function” is enable.Used to recall or store a group scene. Up to 16 scenes are available for the DALI gateway. The KNX scene number is defined as follows:</p> <p>Set an 8bit instruction as (binary code): FXNNNNNN</p> <p>F: call the scene for '0'; store the scene for '1';</p> <p>X:0;</p> <p>NNNNNN: Scene number (0...63).</p> <p>The parameter setting option is 1~64. In fact, the scene telegram received by the communication object corresponds to 0~63. As follows:</p> <table><tr><td>Scene number</td><td>Call the message value of the scene object</td><td>Store the message value of the scene object</td></tr><tr><td>Scene 1</td><td>0</td><td>128</td></tr><tr><td>Scene 2</td><td>1</td><td>129</td></tr><tr><td>Scene 3</td><td>2</td><td>130</td></tr><tr><td>...</td><td>...</td><td>...</td></tr><tr><td>Scene 64</td><td>63</td><td>191</td></tr></table> <p>Such as setting the scene 1 of this parameter, the scene telegram received by the communication object should be 0.</p>						Scene number	Call the message value of the scene object	Store the message value of the scene object	Scene 1	0	128	Scene 2	1	129	Scene 3	2	130	...	...	...	Scene 64	63	191
Scene number	Call the message value of the scene object	Store the message value of the scene object																					
Scene 1	0	128																					
Scene 2	1	129																					
Scene 3	2	130																					
...	...	...																					
Scene 64	63	191																					

Table 6.3 “X: Group” Communication object

## 6.4. Channel Communication Object of a Single DALI Device

There are 64 DALI devices in the channel. The communication objects of each DALI device are the same and independent of each other. The following is an example of one of the devices:

Number ^	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	Data Type	Priority
315	Output A ECG 1-...	Disable function			1 bit	C	-	W	-	-	enable	Low
316	Output A ECG 1-...	Switch			1 bit	C	-	W	-	-	switch	Low
317	Output A ECG 1-...	Relative dimming			4 bit	C	-	W	-	-	dimming control	Low
318	Output A ECG 1-...	Brightness dimming			1 byte	C	-	W	-	-	percentage (0..100%)	Low
319	Output A ECG 1-...	Switch status			1 bit	C	R	-	T	-	switch	Low
320	Output A ECG 1-...	Brightness status			1 byte	C	R	-	T	-	percentage (0..100%)	Low
321	Output A ECG 1-...	Reset Operating hours			1 bit	C	-	W	-	-	reset	Low
322	Output A ECG 1-...	Operating hours			4 bytes	C	R	-	T	-	time lag (s)	Low
323	Output A ECG 1-...	Life time exceeded			1 bit	C	R	-	T	-	alarm	Low
324	Output A ECG 1-...	ECG/Lamp Failure status			2 bytes	C	-	-	T	-	diagnostic value	Low

### Fluorescent Lamp

325	Output A ECG 1-...	Relative percentage colour temperature			1 byte	C	-	W	-	-	percentage (0..100%)	Low
328	Output A ECG 1-...	Relative colour Temperature			4 bit	C	-	W	-	-	dimming control	Low
332	Output A ECG 1-...	Relative percentage colour temperature, status			1 byte	C	R	-	T	-	percentage (0..100%)	Low

### ECG with Colour control\_RGB(Combined object)

325	Output A ECG 1-...	RGB colour value			3 bytes	C	-	W	-	-	RGB value 3x(0..255)	Low
332	Output A ECG 1-...	RGB colour value, status			3 bytes	C	R	-	T	-	RGB value 3x(0..255)	Low
325	Output A ECG 1-...	HSV Hue(H) value			1 byte	C	-	W	-	-	angle (degrees)	Low
326	Output A ECG 1-...	HSV Saturation(S) value			1 byte	C	-	W	-	-	percentage (0..100%)	Low
328	Output A ECG 1-...	Relative HSV Hue(H) value			4 bit	C	-	W	-	-	dimming control	Low
329	Output A ECG 1-...	Relative HSV Saturation(S) value			4 bit	C	-	W	-	-	dimming control	Low
332	Output A ECG 1-...	HSV Hue(H) value, status			1 byte	C	R	-	T	-	angle (degrees)	Low
333	Output A ECG 1-...	HSV Saturation(S) value, status			1 byte	C	R	-	T	-	percentage (0..100%)	Low

### ECG with Colour control\_HSV(Separated objects)

325	Output A ECG 1-...	RGBW colour value			6 bytes	C	-	W	-	-	RGBW value 4x(0..100%)	Low
332	Output A ECG 1-...	RGBW colour value, status			6 bytes	C	R	-	T	-	RGBW value 4x(0..100%)	Low

### ECG with Colour control\_RGBW(Combined object)

325	Output A ECG 1-...	HSV Hue(H) value			1 byte	C	-	W	-	-	angle (degrees)	Low
326	Output A ECG 1-...	HSV Saturation(S) value			1 byte	C	-	W	-	-	percentage (0..100%)	Low
327	Output A ECG 1-...	White colour value			1 byte	C	-	W	-	-	percentage (0..100%)	Low
328	Output A ECG 1-...	Relative HSV Hue(H) value			4 bit	C	-	W	-	-	dimming control	Low
329	Output A ECG 1-...	Relative HSV Saturation(S) value			4 bit	C	-	W	-	-	dimming control	Low
331	Output A ECG 1-...	Relative white colour value			4 bit	C	-	W	-	-	dimming control	Low
332	Output A ECG 1-...	HSV Hue(H) value, status			1 byte	C	R	-	T	-	angle (degrees)	Low
333	Output A ECG 1-...	HSV Saturation(S) value, status			1 byte	C	R	-	T	-	percentage (0..100%)	Low
334	Output A ECG 1-...	White colour value, status			1 byte	C	R	-	T	-	percentage (0..100%)	Low

### ECG with Colour control\_HSVW(Separated objects)

325	Output A ECG 1-...	Colour X value			2 bytes	C	-	W	-	-	pulses	Low
326	Output A ECG 1-...	Colour Y value			2 bytes	C	-	W	-	-	pulses	Low
332	Output A ECG 1-...	Colour X value, status			2 bytes	C	R	-	T	-	pulses	Low
333	Output A ECG 1-...	Colour Y value, status			2 bytes	C	R	-	T	-	pulses	Low

### ECG with Colour control\_XY Colour

Number ^	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	I	Data Type	Priority
324	Output A ECG 1-...	ECG/Lamp Failure status			1 bit	C	-	-	T	-	-	alarm	Low
335	Output A ECG 1-...	Converter, test start			1 byte	C	-	W	-	-	-	converter test control	Low
336	Output A ECG 1-...	Converter, test result			6 bytes	C	R	-	T	-	-	DALI converter test result	Low
337	Output A ECG 1-...	Converter, status			2 bytes	C	R	-	T	-	-	DALI converter status	Low
338	Output A ECG 1-...	Converter battery, status			2 bytes	C	R	-	T	-	-	Battery Information	Low

### ECG with Self-Contained Battery Lamp (non-switchable)


Fig.6.4 “X: ECG” Communication object

NO.	Name	Object function	Types	Attributes	DPT
<b>315</b>	<b>Output X ECG y-{{...}}</b>	<b>Disable function</b>	<b>1bit</b>	<b>C,W</b>	<b>1.003 enable</b>
<p>The communication object is visible when "Disable function" is enable.Used for ECG disable/enable control, the trigger value is defined by the parameter, the device reboot is enabled by default.</p> <p>The name in parentheses changes with the parameter "Description (max 30char.)". If description is empty, display "Output X ECG y-..." by default. The same below.</p>					
<b>316</b>	<b>Output X ECG y-{{...}}</b>	<b>Switch</b>	<b>1bit</b>	<b>C,W</b>	<b>1.001 Switch</b>
<p>This communication object is not visible when the operation mode is "Permanent mode". Used to switch on or off the ECG, y=1..64.</p> <p>The value for "Switch on" can be defined by a parameter template. See <a href="#">section 5.4.1</a> for details.</p>					
<b>317</b>	<b>Output X ECG y-{{...}}</b>	<b>Relative dimming</b>	<b>4bit</b>	<b>C,W</b>	<b>3.007 dimming control</b>
<p>This communication object is used for relative dimming of the ECG. The highest bit Bit4 decides to brighten or darken, Bit 0..3 determines the dimming size, and Bit 0..3 is 0 to stop dimming. Refer to object 29 for the correspondence between the value of the relatively dimmed telegram and the change in brightness.</p>					
<b>318</b>	<b>Output X ECG y-{{...}}</b>	<b>Brightness value</b>	<b>1byte</b>	<b>C,W</b>	<b>5.001 percentage(0..100%)</b>
<p>This communication object is not visible when the operation mode is "Permanent mode".Used to set the brightness value of the ECG.</p>					
<b>319</b>	<b>Output X ECG y-{{...}}</b>	<b>Switch status</b>	<b>1bit</b>	<b>C,R,T</b>	<b>1.001 Switch</b>
<p>This communication object is used to send the switch status of the ECG.</p>					
<b>320</b>	<b>Output X ECG y-{{...}}</b>	<b>Brightness status</b>	<b>1byte</b>	<b>C,R,T</b>	<b>5.001 percentage(0..100%)</b>
<p>This communication object is used to send the brightness status of the ECG.</p>					
<b>321</b>	<b>Output X ECG y-{{...}}</b>	<b>Reset      Operating hours</b>	<b>1bit</b>	<b>C,W</b>	<b>1.015 reset</b>
<p>This communication object is used to reset the operating hours of the lamp to 0.</p>					

322	Output X ECG y-{{...}}	Operation hours	4byte	C,R,T	13.100 time lag(s)
<p>This communication object is used to send the operation hours of the lamp. Time unit: seconds. Send once every hour.</p> <p><b>Note: This object supports the write count time or the reset count time to 0, but the W attribute needs to be set via ETS. Normally, W does not set.</b></p>					
323	Output X ECG y-{{...}}	Life time exceeded	1bit	C,R,T	1.005 alarm
<p>This communication object sends status information when the operation hours of the lamp exceeds the life time limit of the parameter configuration.</p>					
324	Output X ECG y-{{...}}	ECG/Lamp Failure status	1bit 1byte 2byte	C, R,T	1.005 alarm 238.600 DALI Diagnostics 237.600 DALI_Control_Gear_Diagnostics
<p>Displayed according to the parameter Object type of ECG /Lamp/converter failure. Used to send failure status of the lamp and ECG.</p>					
325	Output X ECG y-{{...}}	Converter, test start	1byte	C,W	20.611 converter test control
<p>This communication object is used to start test for converter. Telegrams:</p> <ul style="list-style-type: none"> <li>0 : Reserved</li> <li>1 : Start Function Test (FT), Acc. DALI Cmd.227</li> <li>2 : Start Duration Test (DT), Acc. DALI Cmd.228</li> <li>3 : Start Partial Duration Test (PDT), <b>not supported</b></li> <li>4 : Stop Test, Acc. DALI Cmd.229</li> <li>5 : Reset Function Test (FT) Done, Acc. DALI Cmd. 230</li> <li>6 : Reset Duration Test (DT) Done, Acc. DALI Cmd. 231</li> <li>7..255 : Reserved</li> </ul> <p><b>Note: Parallel tests to the same DALI converter will be supported. This DPT controls a test of a DALI converter. It also allows to stop a running test.</b></p>					

326	Output X ECG y-{{...}}	Converter, test result	6byte	C,R,T	245.600 DALI converter test result
-----	------------------------	------------------------	-------	-------	------------------------------------

This communication object is used to output the test result of converter. Telegram fields LTRF, LTRP, SD, SP, LDTR are defined as following:



Field	Description	Range	Encoding
LTRF	Test result of last function test (FT)	0..15	0: Unknown 1: Passed in time 2: Passed max delay exceeded 3: Failed, test executed in time 4: Failed, max delay exceeded 5: <b>Not supported</b> , and stay 0 6..15: Reserved
LTRD	Test result of last duration test (DT)	0..15	0: Unknown 1: Passed in time 2: Passed max delay exceeded 3: Failed, test executed in time 4: Failed, max delay exceeded 5: <b>Not supported</b> , and stay 0 6..15: Reserved
LTRP	Test result of last partial duration test (PDT)	0..15	<b>Not supported</b> , and stay 0
SF	Start method of last function test (FT)	0..3	0: Unknown 1: Started automatically 2: Started by Gateway 3: Reserved



SD	Start method of last duration test (DT)	0..3	0: Unknown 1: Started automatically 2: Started by Gateway 3: Reserved
SP	Start method of last partial duration test (PDT)	0..3	Not supported, and stay 0
LDTR	Contains the battery discharge time as the result of the last successful duration test (DT)	0..510	Not supported, and stay 0
LPDTR	Provides the remaining Battery Charge Level after the last partial duration test (PDT)	0..255	Not supported, and stay 0

327	Output X ECG y-{{...}}	Converter, status	2byte	C,R,T	244.600 DALI converter status
-----	------------------------	-------------------	-------	-------	-------------------------------

This communication object is used to output the status of converter. Telegram fields CM, HS, FP, DP, PP, CF are defined as following:

<b>Format:</b>	2 octets: N4B4N2N2N2N2
octet nr.	2 <sub>MSB</sub> 1 <sub>LSB</sub>
field names	CM HS FP DP PP CF
encoding	NNNNBBBB NNNNNNNN
<b>Unit:</b>	None.
<b>Resol.</b>	(not applicable)
<b>PDT:</b>	PDT_GENERIC_02

Field	Description	Range	Encoding
CM	Converter mode according to the DALI converter state machine	0..15	0: Unknown 1: Normal mode active, all OK 2: Inhibit mode active 3: Hardwired inhibit mode active 4: Rest mode active 5: Emergency mode active 6: Extended emergency mode active 7: Function test in progress 8: Duration test in progress 9..15: Reserved
HS	Hardware Status	0..3	0: Hardwired Inhibit is active 1: Hardwired switch is on 2..3: Reserved
FP	Function Test Pending	0..3	0: Unknown 1: No test pending 2: Test pending 3: Reserved
DP	Duration Test Pending	0..3	Define is same as FP
PP	Partial Duration Test Pending	0..3	<b>Not supported</b> , and stay 0
CF	Converter Failure	0..3	0: Unknown 1: No failure detected 2: Failure detected 3: Reserved

328	Output X ECG y-{{...}}	Converter battery, status	2byte	C,R,T	DTP 246.600 Battery info
-----	------------------------	---------------------------	-------	-------	--------------------------

This communication object is used to output the status of converter battery.

<u>Format:</u>	2 octets: rsBsUs
octet nr.	2 <sub>MSB</sub> 1 <sub>LSB</sub>
field names	0000 BS BCL
encoding	rrrrrBBB NNNNNNNN
<u>Unit:</u>	None.
<u>Resol.</u>	(not applicable)
<u>PDT:</u>	PDT_GENERIC_02

Field	Description	Range	Encoding
BS	Battery status	0..1	Bit 0: Battery failure, according DALI Cmd. 252 Bit 1: Battery duration failure, according DALI Cmd. 252 Bit 2: Battery fully charged Bit 3..7: Reserved
BCL	Battery charge level	0..255	According to DALI Cmd. 241 0: deep discharge point ... 254: fully charged 255: unknown

Table 6.4 “X: ECG” Communication object

**Note:** Communication objects 325-336 are similar to the objects in [Section 6.3](#) and are not repeated here.

## 6.5. Channel Communication Object of a Single DALI Sensor

Numb	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	I	Data Type	Priority
1855	DALI A Motion sensor 1-...	Output value,movement			1 bit	C	-	-	T	-	-	switch	Low
1856	DALI A Motion sensor 1-...	Disable function,movement			1 bit	C	-	W	-	-	-	enable	Low
1857	DALI A Motion sensor 1-...	End presence (only off telegram)			1 bit	C	-	W	-	-	-	switch	Low
1858	DALI A Motion sensor 1-...	Failure status,movement			1 bit	C	R	-	T	-	-	alarm	Low
1859	DALI A Motion sensor 1-...	External brightness sensor			2 bytes	C	R	-	T	-	-	lux (Lux)	Low
1860	DALI A Motion sensor 1-...	Output value,brightness alarm			1 bit	C	-	-	T	-	-	alarm	Low

Fig.6.5 “DALI X Motion sensor” Communication object

NO.	Name	Object function	Types	Attributes	DPT
1855	<b>DALI X Motion sensor</b> <b>y-{{...}}</b>	<b>Output value,movement</b>	<b>1bit</b> <b>1byte</b>	<b>C,T</b>	<b>1.001 switch</b> <b>5.001 percentage</b> <b>5.010 counter pulses</b> <b>17.001 scene number</b>
<p>This communication object is used to send value when there is a movement, object datatype and range is depending on the parameters.</p> <p>The name in parentheses changes with the parameter “Description (max 30char.)”. If description is empty, display “DALI X Motion sensor y-...” by default. The same below.</p>					
1856	<b>DALI X Motion sensor</b> <b>y-{{...}}</b>	<b>Disable</b> <b>function,movement</b>	<b>1bit</b>	<b>C,W</b>	<b>1.003 enable</b>
<p>This communication object is used to whether disable movement detection. object value is defined by parameter.</p>					
1857	<b>DALI X Motion sensor</b> <b>y-{{...}}</b>	<b>End presence (only off telegram)</b>	<b>1bit</b>	<b>C,W</b>	<b>1.001 switch</b>
<p>The communication object is used to receive the switch status of actuator, enter dead time when receive telegram OFF, and suppress presence detection. Telegram ON is no meaning.</p>					
1858	<b>DALI X Motion sensor</b> <b>y-{{...}}</b>	<b>Failure status,movement</b>	<b>1bit</b>	<b>C,R,T</b>	<b>1.005 alarm</b>
<p>The communication object is used to send the failure status of movement detector to KNX bus.</p> <p>Telegram:</p> <p>1——Failure</p> <p>0——Normal</p>					

1859	DALI X Motion sensor y-{{...}}	External brightness sensor	2byte	C,R,T	9.004 lux(lux)
The communication object is used to send the brightness value to KNX bus.					
1860	DALI X Motion sensor y-{{...}}	Output value,brightness alarm	1bit	C,T	1.005 alarm
The communication object is used to send value when brightness value is lower than threshold. object value is defined by parameter.					

Table 6.5 “DALI X Motion sensor” Communication object